

Standard AC Motors

Constant Speed Motors

Induction Motors

	Page
Features and Types of Induction Motors	A-20
General Specifications	A-25
World K Series [1 W~90 W (1/750 HP~1/8 HP)] ...	A-26
BH Series [200 W (1/4 HP)]	A-60
2-Pole, High-Speed Type [40 W~150 W (1/19 HP~1/5 HP)]	A-72

Standard AC Motors											
Introduction											
Induction Motors											
Reversible Motors	Electro- magnetic Brake Motors	V Series	Clutch & Brake Motors	Synchronous Motors	Low-Speed Synchronous Motors	Watertight, Dust-resistant Motors	Torque Motors	Right-Angle Gearheads	Linear Heads	Brake Pack	Accessories
											Installation

1 W, 3 W
(1/750 HP)6 W
(1/125 HP)15 W
(1/50 HP)25 W
(1/30 HP)40 W
(1/19 HP)60 W
(1/12 HP)90 W
(1/8 HP)200 W
(1/4 HP)2-Pole
40-150 W
(1/19-1/5 HP)

Features and Types of Induction Motors

■ Features of Induction Motors

● Optimal for Uni-Directional and Continuous Operation

Induction motors are optimal for uni-directional and continuous operation such as a conveyor system.

● Easy Operation

All you need is to connect a capacitor and plug the motor into an AC power supply, and the motor can be easily operated. (No capacitor is needed for a three-phase motor.)

● Extensive Lineup

The World **K** Series and **BH** Series are available.

We have models with an output power range of 1 W (1/750 HP) to 200 W (1/4 HP), so that you can find one that meets your specific application.


● Compatible with Various Gearheads

Combination with a gearhead allows the motor to reduce to a required speed or generate higher torque.

● (RoHS) RoHS-Compliant

The World **K** Series and **BH** Series conform to the RoHS Directive that prohibits the use of six chemical substances including lead and cadmium.


■ Types of Induction Motors

Series	Features, Lineup								
World K Series  	<ul style="list-style-type: none"> ● Conforms to Safety Standards All World K Series models have a built-in overheat protection device and conform to major safety standards. ● Applicable Standards UL/CSA Standards Certified under the China Compulsory Certification System* (CCC System) CE Marking (Low Voltage Directive) *Except Conduit Box Type ● Motor Overheat Protection Device Thermal protector, Impedance protected ● Global Voltage Specifications The World K Series supports the power supply voltages used in major countries. Motors meeting the local voltage standard are readily available in major countries in Europe, Asia and North America. <p>● The Motor Bearing Life is Twice as Long as a Conventional Type A motor's life is determined by its bearing. We adopted high-performance bearing grease to lubricate this important component. As a result, the bearings of World K Series motors last twice as long as conventional bearings. [Excluding 1 W (1/750 HP) and 3 W (1/250 HP) type.]</p> <p>● Protective Earth Terminal on the Motor </p> <p>● Lineup</p> <table border="1"> <tbody> <tr> <td>Frame Size</td><td>□ 42 mm (□ 1.65 in.) ~ □ 90 mm (□ 3.54 in.)</td></tr> <tr> <td>Output Power</td><td>Lead Wire Type: 1 W ~ 90 W (1/750 HP ~ 1/8 HP) Terminal Box Type: 25 W ~ 90 W (1/30 HP ~ 1/8 HP) Conduit Box Type: 25 W ~ 90 W (1/30 HP ~ 1/8 HP) 2-Pole, High-Speed Type: 40 W ~ 150 W (1/19 HP ~ 1/5 HP)</td></tr> <tr> <td>Voltage</td><td>Single-Phase 110/115 VAC Single-Phase 220/230 VAC Three-Phase 200/220/230 VAC</td></tr> </tbody> </table>	Frame Size	□ 42 mm (□ 1.65 in.) ~ □ 90 mm (□ 3.54 in.)	Output Power	Lead Wire Type: 1 W ~ 90 W (1/750 HP ~ 1/8 HP) Terminal Box Type: 25 W ~ 90 W (1/30 HP ~ 1/8 HP) Conduit Box Type: 25 W ~ 90 W (1/30 HP ~ 1/8 HP) 2-Pole, High-Speed Type: 40 W ~ 150 W (1/19 HP ~ 1/5 HP)	Voltage	Single-Phase 110/115 VAC Single-Phase 220/230 VAC Three-Phase 200/220/230 VAC		
Frame Size	□ 42 mm (□ 1.65 in.) ~ □ 90 mm (□ 3.54 in.)								
Output Power	Lead Wire Type: 1 W ~ 90 W (1/750 HP ~ 1/8 HP) Terminal Box Type: 25 W ~ 90 W (1/30 HP ~ 1/8 HP) Conduit Box Type: 25 W ~ 90 W (1/30 HP ~ 1/8 HP) 2-Pole, High-Speed Type: 40 W ~ 150 W (1/19 HP ~ 1/5 HP)								
Voltage	Single-Phase 110/115 VAC Single-Phase 220/230 VAC Three-Phase 200/220/230 VAC								
BH Series  	<ul style="list-style-type: none"> ● Smallest Frame Size among 200 W (1/4 HP) Motors These motors achieve a high output of 200 W (1/4 HP) with a frame size of 104 mm (4.09 in.). ● Hypoid Gear-Employed Right Angle Type is Available. ● "Combination Type" for Easy Installation With each combination type, the motor and gearhead come pre-assembled for easy installation into your equipment. ● Conforms to Safety Standards and Global Voltage Specifications <p>● Lineup</p> <table border="1"> <tbody> <tr> <td>Frame Size</td><td>□ 104 mm (□ 4.09 in.)</td></tr> <tr> <td>Output Power</td><td>200 W (1/4 HP)</td></tr> <tr> <td>Type</td><td>Cable Type: Right-Angle, Hollow Shaft Type, Right-Angle, Solid Shaft Type, Parallel Shaft Type, Round Shaft Type Terminal Box Type: Right-Angle, Hollow Shaft Type, Right-Angle, Solid Shaft Type, Parallel Shaft Type, Round Shaft Type</td></tr> <tr> <td>Voltage</td><td>Single-Phase 110/115 VAC Single-Phase 220/230 VAC Three-Phase 200/220/230 VAC</td></tr> </tbody> </table>	Frame Size	□ 104 mm (□ 4.09 in.)	Output Power	200 W (1/4 HP)	Type	Cable Type: Right-Angle, Hollow Shaft Type, Right-Angle, Solid Shaft Type, Parallel Shaft Type, Round Shaft Type Terminal Box Type: Right-Angle, Hollow Shaft Type, Right-Angle, Solid Shaft Type, Parallel Shaft Type, Round Shaft Type	Voltage	Single-Phase 110/115 VAC Single-Phase 220/230 VAC Three-Phase 200/220/230 VAC
Frame Size	□ 104 mm (□ 4.09 in.)								
Output Power	200 W (1/4 HP)								
Type	Cable Type: Right-Angle, Hollow Shaft Type, Right-Angle, Solid Shaft Type, Parallel Shaft Type, Round Shaft Type Terminal Box Type: Right-Angle, Hollow Shaft Type, Right-Angle, Solid Shaft Type, Parallel Shaft Type, Round Shaft Type								
Voltage	Single-Phase 110/115 VAC Single-Phase 220/230 VAC Three-Phase 200/220/230 VAC								

Features of Gearheads

● Easy Speed Reduction and Torque Increase

Combination with a gearhead allows the motor to reduce to a required speed or generate higher torque.



- Combine gearheads with a pinion shaft type motor.

- Gearheads of World **K** Series are sold separately.

BH Series comes with the gearhead pre-assembled.


● Wide Variety of Products

Gearheads come in various types including the long life, low noise gearhead and right-angle gearhead. Most gearheads are available with 20 different gear ratios from 3:1 to 180:1.

● RoHS RoHS-Compliant

Gearheads conform to the RoHS Directive that prohibits the use of six chemical substances including lead and cadmium.

Types of Gearheads

Types	Features
Long Life, Low Noise GN-S Gearhead 	<p>● Long Rated Life of 10000 Hours The GN-S gearhead achieves a long rated life of 10000 hours, twice the level of a conventional gearhead, by adopting a large, specially designed bearing and reinforced gears.</p> <p>● Low Noise Design The GN-S gearhead generates less noise thanks to gears with a special shape and surface machining assembled with the use of advanced technology.</p> <p>● Applicable Products 6 W (1/125 HP), 15 W (1/50 HP), 25 W (1/30 HP) or 40 W (1/19 HP) GN pinion motor</p> 
Long Life GE-S Gearhead 	<p>● Long Rated Life of 10000 Hours The GE-S gearhead achieves a long rated life of 10000 hours, twice the level of a conventional gearhead, by adopting a large, specially designed bearing and reinforced gears.</p> <ul style="list-style-type: none"> The GE-S gearhead comes with a tapped hole at the tip of the shaft. <p>● Applicable Products 60 W (1/12 HP) or 90 W (1/8 HP) GE pinion motor</p>
Right-Angle Gearhead → Page A-239 	<p>● Ideal Space-Saving Solution The gear shaft is positioned at right angles with the motor shaft, enabling space-saving.</p> <p>● Hollow Shaft and Solid Shaft Types are Available Select an appropriate type that suits your specific application.</p> <ul style="list-style-type: none"> Solid shaft type of GE pinion gearhead comes with a tapped hole at the tip of the shaft. <p>● Applicable Products 25 W (1/30 HP), 40 W (1/19 HP), 60 W (1/12 HP) or 90 W (1/8 HP) pinion motor</p>

■ Product Line of Induction Motors (RoHS)

Standard AC Motors	Series	Voltage (VAC)	Type	Motor Frame Size, Output Power										
				□42 mm (□1.65 in.)	□60 mm (□2.36 in.)	□70 mm (□2.76 in.)	□80 mm (□3.15 in.)			□90 mm (□3.54 in.)			□104 mm (□4.09 in.)	
				1 W, 3 W (1/750 HP, 1/250 HP)	6 W (1/125 HP)	15 W (1/50 HP)	25 W (1/30 HP)	40 W (1/19 HP)	60 W (1/12 HP)	40 W (1/19 HP)	60 W (1/12 HP)	90 W (1/8 HP)	150 W (1/5 HP)	200 W (1/4 HP)
World K Series	Single-Phase 110/115	Lead Wire	●	●	●	●				●	●	●		
		Terminal Box					●			●	●	●		
		Conduit Box					●			●	●	●		
	Single-Phase 220/230	Lead Wire	●	●	●					●	●	●		
		Terminal Box	●		●		●			●	●	●		
		Conduit Box			●					●	●	●		
	Three-Phase 200/220/230	Lead Wire	●		●					●	●	●		
		Terminal Box	●		●					●	●	●		
		Conduit Box			●					●	●	●		
2-Pole, High-Speed Type	Single-Phase 110/115	Lead Wire					●	●		●	●	●	●	
	Single-Phase 220/230	Lead Wire					●	●		●	●	●	●	
	Three-Phase 200/220/230	Lead Wire								●	●	●	●	
		Terminal Box											●	
BH Series	Single-Phase 110/115	Cable											●	
		Terminal Box											●	
	Single-Phase 220/230	Cable											●	
	Three-Phase 200/220/230	Terminal Box											●	

■ Product Line of Gearheads (RoHS)

Gearhead			Applicable Motor			Rated Life (hours)	Low Noise
Type of Gearhead	Type of Pinion	Series	Output Power	Type of Pinion			
Parallel Shaft	Long Life, Low Noise GN-S Gearhead	GN Type Pinion Shaft	World K Series	6 W~40 W (1/125 HP~1/19 HP)	GN Type Pinion Shaft	10000	●
	GN-K Gearhead	GN Type Pinion Shaft	World K Series	1 W~40 W (1/750 HP~1/19 HP)	GN Type Pinion Shaft	5000	
	Long Life GE-S Gearhead	GE Type Pinion Shaft	World K Series	60 W, 90 W (1/12 HP, 1/8 HP)	GE Type Pinion Shaft	10000	
Right-Angle Shaft	Hollow Shaft Gearhead	GN Type Pinion Shaft	World K Series	25 W, 40 W (1/30 HP, 1/19 HP)	GN Type Pinion Shaft	5000	
		GE Type Pinion Shaft	World K Series	60 W, 90 W (1/12 HP, 1/8 HP)	GE Type Pinion Shaft	5000	
	Solid Shaft Gearhead	GN Type Pinion Shaft	World K Series	25 W, 40 W (1/30 HP, 1/19 HP)	GN Type Pinion Shaft	5000	
		GE Type Pinion Shaft	World K Series	60 W, 90 W (1/12 HP, 1/8 HP)	GE Type Pinion Shaft	5000	

System Configuration

Gearheads (Sold separately)

Parallel Shaft Gearheads ([Page A-21](#))

Right-Angle Gearheads ([Page A-239](#))

Hollow Shaft Type Solid Shaft Type



Induction Motors

Motor
(Pinion Shaft)



Capacitor Cap
(Included)

Capacitor (Included)

AC Power Supply
(Main power supply)

Peripheral Equipment (Sold separately)

① Brake Pack
SB50W
([Page A-277](#))



② Speed Controller
FE100/FE200
([Page B-156](#))



Accessories (Sold separately)



③ Mounting Brackets
([Page A-288](#))



④ Flexible Couplings
([Page A-292](#))

No.	Product Name	Overview	Page
①	Brake Pack	Use this brake pack to stop the motor instantaneously, perform bi-directional operation, and more.	A-277
②	Speed Controller	Combine this Speed Controller with a three-phase motor for easy speed control. Equipped with a digital display.	B-156
③	Mounting Brackets	Dedicated mounting bracket for the motor and gearhead.	A-288
④	Flexible Couplings	Clamp type coupling that connects the motor or gearhead shaft to the driven shaft.	A-292

● Example of System Configuration

(Sold separately)



● Gearheads cannot be combined with round shaft type motors.

● The system configuration shown above is an example. Other combinations are available.

Product Number Code

World K Series

5 I K 40 GN - AW 2 T U

(1) (2) (3) (4) (5) (6) (7) (8) (9)

(1)	Motor Frame Size	O: 42 mm (1.65 in.) 2: 60 mm (2.36 in.) 3: 70 mm (2.76 in.) 4: 80 mm (3.15 in.) 5: 90 mm (3.54 in.)
(2)	Motor Type	I: Induction Motor
(3)	Series	K: K Series
(4)	Output Power (W)	(Example) 40: 40 W (1/19 HP)
(5)	Motor Shaft Type, Type of Pinion	A: Round Shaft GN: GN Type Pinion Shaft GE: GE Type Pinion Shaft
(6)	Power Supply Voltage/ Number of Poles	AW: Single-Phase 110/115 VAC 4-Pole BW: Single-Phase 110/115 VAC 2-Pole CW: Single-Phase 220/230 VAC 4-Pole DW: Single-Phase 220/230 VAC 2-Pole SW: Three-Phase 200/220/230 VAC 4-Pole TW: Three-Phase 200/220/230 VAC 2-Pole
(7)	2, 3: RoHS-Compliant	
(8)	T: Terminal Box Type	
(9)	Included Capacitor	U: For Single-Phase 110/115 VAC E: For Single-Phase 220/230 VAC Blank: Three-Phase Type

● The **U** and **E** at the end of the model name indicate that the unit includes a capacitor. These letters are not listed on the motor nameplate.

When the motor is approved under various safety standards, the model name on the nameplate is the approved model name. → Page G-11

(Example) Model: **5IK40GN-AW2U** → Motor nameplate and product approved under various safety standards: **5IK40GN-AW2**

Conduit Box Type

5 I K 40 GN - F C H

(1) (2) (3) (4) (5) (6) (7) (8)

(1)	Motor Frame Size	4: 80 mm (3.15 in.) 5: 90 mm (3.54 in.)
(2)	Motor Type	I: Induction Motor
(3)	Series	K: K Series
(4)	Output Power (W)	(Example) 40: 40 W (1/19 HP)
(5)	Motor Shaft Type, Type of Pinion	A, AA: Round Shaft GN: GN Type Pinion Shaft GE: GE Type Pinion Shaft
(6)	Power Supply Voltage	F: Single-Phase 110/115 VAC E: Single-Phase 220/230 VAC S: Three-Phase 200/220/230 VAC
(7)	C: With Capacitor	
(8)	H: Conduit Box Type	

Gearhead

5 GN 50 SA

(1) (2) (3) (4)

(1)	Gearhead Frame Size	O: 42 mm (1.65 in.) 2: 60 mm (2.36 in.) 3: 70 mm (2.76 in.) 4: 80 mm (3.15 in.) 5: 90 mm (3.54 in.)
(2)	Type of Pinion	GN: GN Type Pinion GE: GE Type Pinion
(3)	Gear Ratio	(Example) 50: Gear Ratio of 50:1 10X: denotes the decimal gearhead of gear ratio 10:1
(4)	GN Type Pinion	SA: Long Life, Low Noise GN-S Gearhead, RoHS-Compliant KA: GN-K Gearhead, RoHS-Compliant RH: Right-Angle, Hollow Shaft Gearhead, RoHS-Compliant RAA: Right-Angle, Solid Shaft Gearhead, RoHS-Compliant
	GE Type Pinion	SA: Long Life GE-S Gearhead, RoHS-Compliant RH: Right-Angle, Hollow Shaft Gearhead, RoHS-Compliant RAA: Right-Angle, Solid Shaft Gearhead, RoHS-Compliant

BH Series

BH I 6 2 F T - 100 RH

(1) (2) (3) (4) (5) (6) (7) (8)

(1)	Series	BH: BH Series
(2)	Motor Type	I: Induction Motor
(3)	Motor Frame Size	6: 104 mm (4.09 in.)
(4)	Output Power (W)	(Example) 2: 200 W (1/4 HP)
(5)	Power Supply Voltage	F: Single-Phase 110/115 VAC E: Single-Phase 220/230 VAC S: Three-Phase 200/220/230 VAC
(6)	T: Terminal Box Type	Blank: Cable Type
(7)	Gear Ratio, Motor Shaft Type	A: Round Shaft Type Number: Gear Ratio of Combination Type
(8)	Type of Gearhead (Combination type only)	RH: Right-Angle, Hollow Shaft Type RA: Right-Angle, Solid Shaft Type Blank: Parallel Shaft Type

General Specifications

World K Series

◇ 1 W (1/750 HP), 3 W (1/250 HP) Type

Item	Specifications
Insulation Resistance	100 MΩ or more when 500 VDC megger is applied between the windings and the case after rated operation under normal ambient temperature and humidity.
Dielectric Strength	Sufficient to withstand 1.5 kVAC at 50 Hz or 60 Hz applied between the windings and the case for 1 minute after rated operation under normal ambient temperature and humidity.
Temperature Rise	Temperature rise of windings are 75°C (135°F) or less measured by the resistance change method after rated operation under normal ambient temperature and humidity with connecting a gearhead or equivalent heat radiation plate*.
Insulation Class	UL/CSA standards: Class A [105°C (221°F)], EN standards: Class E [120°C (248°F)]
Overheat Protection	Impedance protected
Ambient Temperature	-10~+40°C (+14~+104°F) (non-freezing)
Ambient Humidity	85% or less (non-condensing)
Degree of Protection	IP20

◇ 6 W (1/125 HP)~90 W (1/8 HP) Type, 2-Pole/High-Speed Type

Item	Specifications
Insulation Resistance	100 MΩ or more when 500 VDC megger is applied between the windings and the case after rated operation under normal ambient temperature and humidity.
Dielectric Strength	Sufficient to withstand 1.5 kVAC at 50 Hz or 60 Hz applied between the windings and the case for 1 minute after rated operation under normal ambient temperature and humidity.
Temperature Rise	Temperature rise of windings are 80°C (144°F) or less measured by the resistance change method after rated operation under normal ambient temperature and humidity with connecting a gearhead or equivalent heat radiation plate*. [Three-phase type: 70°C (126°F) or less]
Insulation Class	Class B [130°C (266°F)]
Overheat Protection	6 W (1/125 HP) type has impedance protection. All others have built-in thermal protector (automatic return type) Open: 130±5°C (266±9°F), Close: 82±15°C (179.6±27°F)
Ambient Temperature	Single-phase 110/115 VAC, Single-phase 220/230 VAC, Three-phase 220/230 VAC: -10~+40°C (+14~+104°F) (non-freezing) Three-phase 200 VAC: -10~+50°C (+14~+122°F) (non-freezing)
Ambient Humidity	85% or less (non-condensing)
Degree of Protection	Lead Wire Type: IP20 Terminal Box Type, Conduit Box Type: IP54 (excluding the installation surface of the round shaft type)

* Heat radiation plate (Material: Aluminum)

Motor Type	Size: mm (in.)	Thickness: mm (in.)
1 W (1/750 HP), 3 W (1/250 HP) Type	80×80 (3.15×3.15)	5 (0.20)
6 W (1/125 HP) Type	115×115 (4.53×4.53)	
15 W (1/50 HP) Type	125×125 (4.92×4.92)	
25 W (1/30 HP) Type (2-Pole, High-Speed 4IK40 Type, 4IK60 Type)	135×135 (5.31×5.31)	
40 W (1/19 HP) Type (2-Pole, High-Speed 5IK60 Type)	165×165 (6.50×6.50)	
60 W (1/12 HP), 90 W (1/8 HP), 150 W (1/5 HP) Type	200×200 (7.87×7.87)	

BH Series

Item	Specifications
Insulation Resistance	100 MΩ or more when 500 VDC megger is applied between the windings and the case after rated operation under normal ambient temperature and humidity.
Dielectric Strength	Sufficient to withstand 1.5 kVAC at 50 Hz or 60 Hz applied between the windings and the case for 1 minute after rated operation under normal ambient temperature and humidity.
Temperature Rise	Temperature rise of windings are 70°C (126°F) or less measured by the resistance change method after rated operation under normal ambient temperature and humidity with connecting a gearhead or equivalent heat radiation plate*.
Insulation Class	Class B [130°C (266°F)]
Overheat Protection	Built-in thermal protector (automatic return type) Open: 150±5°C, (302±9°F), Close: 96±15°C (204.8±27°F)
Ambient Temperature	Single-phase 110/115 VAC, Single-phase 220/230 VAC, Three-phase 220/230 VAC: -10~+40°C (+14~+104°F) (non-freezing) Three-phase 200 VAC: -10~+50°C (+14~+122°F) (non-freezing)
Ambient Humidity	85% or less (non-condensing)
Degree of Protection	Cable Type: IP40 Terminal Box Type: IP54 (excluding the installation surface of the round shaft type)

* Heat radiation plate: 230×230 mm (9.06×9.06 in.), Thickness: 5 mm (0.20 in.) (Material: Aluminum)

Induction Motors

1 W (1/750 HP), 3 W (1/250 HP)**Frame Size: □42 mm (□1.65 in.)**

(Gearhead sold separately)

1 W, 3 W
(1/750 HP)6 W
(1/250 HP)15 W
(1/50 HP)25 W
(1/30 HP)40 W
(1/19 HP)60 W
(1/12 HP)90 W
(1/8 HP)200 W
(1/4 HP)2-Pole
40-50 W
(1/19-1/5 HP)**Specifications – Continuous Rating (RoHS)**

Model Lead Wire Type		Output Power W HP	Voltage VAC	Frequency Hz	Current A	Starting Torque mN·m oz-in	Rated Torque mN·m oz-in	Rated Speed r/min	Capacitor μF
Pinion Shaft Type	Round Shaft Type								
(ZP) OIK1GN-AW3U	OIK1A-AW3U	1 1/750	Single-Phase 110	60	0.074	8	8	1200	1.0
			Single-Phase 115		0.078	1.13	1.13		
(ZP) OIK3GN-BW3U	OIK3A-BW3U	3 1/250	Single-Phase 110	60	0.115	6	10	3000	1.5
			Single-Phase 115		0.118	0.85	1.42		

- The **U** at the end of the model name indicates that the unit includes a capacitor. This letter is not listed on the motor nameplate.
- When the motor is approved under various safety standards, the model name on the nameplate is the approved model name. → Page G-11

- Details of safety standards → Page G-2
- Details of RoHS Directive → Page G-38

(ZP): Impedance protected

Product Line**Motor (RoHS)**

Type	Model	
	Pinion Shaft Type	Round Shaft Type
Lead Wire	OIK1GN-AW3U	OIK1A-AW3U
	OIK3GN-BW3U	OIK3A-BW3U

- The following items are included in each product.
Motor, Capacitor, Capacitor Cap, Operating Manual

Parallel Shaft Gearhead (Sold separately) (RoHS)

Gearhead Type	Gearhead Model	Gear Ratio
		Parallel Shaft
GN-K Gearhead	OGN□KA	3, 3.6, 5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180

- Enter the gear ratio in the box (□) within the model name.

- The following items are included in each product.
Gearhead, Mounting Screws, Operating Manual

Gearmotor – Torque Table

- Gearheads are sold separately. Decimal gearheads are not available.
- Enter the gear ratio in the box (□) within the gearhead model name.
- A colored background (■) indicates gear shaft rotation in the same direction as the motor shaft, while the others rotate in the opposite direction.
- The speed is calculated by dividing the motor's synchronous speed (4-pole type; 60 Hz: 1800 r/min, 2-pole type; 60 Hz: 3600 r/min) by the gear ratio. The actual speed is 2~33% less than the displayed value, depending on the load.

◇ 60 Hz

Unit = Upper values: N·m/Lower values: lb-in

Model	Speed r/min	600	500	360	300	240	200	144	120	100	72	60	50	36	30	24	20	18	15	12	10
		Gear Ratio	3	3.6	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150
OIK1GN-AW3U	OGN□KA	0.019 0.168	0.023 0.20	0.032 0.28	0.039 0.34	0.049 0.43	0.058 0.51	0.073 0.64	0.088 0.77	0.11 0.97	0.13 1.15	0.16 1.41	0.19 1.68	0.26 2.3	0.32 2.8	0.35 3.0	0.42 3.7	0.47 4.1	0.57 5.0	0.71 6.2	0.85 7.5

Unit = Upper values: N·m/Lower values: lb-in

Model	Speed r/min	1200	1000	720	600	480	400	288	240	200	144	120	100	72	60	48	40	36	30	24	20
		Gear Ratio	3	3.6	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150
OIK3GN-BW3U	OGN□KA	0.024 0.21	0.029 0.25	0.041 0.36	0.049 0.43	0.061 0.53	0.073 0.64	0.091 0.80	0.11 0.97	0.13 1.15	0.17 1.50	0.20 1.77	0.24 2.1	0.33 2.9	0.40 3.5	0.44 3.8	0.53 4.6	0.59 5.2	0.71 6.2	0.89 7.8	1 8.8

Permissible Overhung Load and Permissible Thrust Load

Motor (Round shaft type) → Page A-16

Gearhead → Page A-16

Permissible Load Inertia J of Gearhead

→ Page A-17

Dimensions Unit = mm (in.)

- Mounting screws are included with gearheads. Dimensions for mounting screws → Page A-310

Lead Wire Type

Motor Model	Gearhead Model	DXF
OIK1GN-AW3U	OGN□KA	
OIK3GN-BW3U		A441U


Mass: Motor 0.3 kg (0.66 lb.)

Gearhead 0.2 kg (0.44 lb.)


Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.

Motor Model	Mass	DXF
OIK1A-AW3U	0.3 kg (0.66 lb.)	
OIK3A-BW3U		A442





Detail Drawing of Protective Earth Terminal



- Enter the gear ratio in the box (□) within the model name.

◇ Capacitor (Included)



◇ Capacitor Dimensions Unit = mm (in.)


Model		Capacitor Model	A	B	C	Mass g (oz.)	Capacitor Cap
Pinion Shaft Type	Round Shaft Type						
OIK1GN-AW3U	OIK1A-AW3U	CH10FAUL	31 (1.22)	14.5 (0.57)	23.5 (0.93)	18 (0.64)	Included
OIK3GN-BW3U	OIK3A-BW3U		31 (1.22)	14.5 (0.57)	23.5 (0.93)	18 (0.64)	

1 W, 3 W
(1/750 HP)
6 W
(1/125 HP)15 W
(1/50 HP)25 W
(1/30 HP)40 W
(1/19 HP)60 W
(1/12 HP)90 W
(1/8 HP)200 W
(1/4 HP)2-Pole
40-50 W
(1/19-1/5 HP)

■ Connection Diagrams

- The direction of motor rotation is as viewed from the shaft end of the motor. CW represents the clockwise direction, while CCW represents the counterclockwise direction.
- Connection diagrams are also valid for the equivalent round shaft type.

OIK1GN-AW3U, OIK3GN-BW3U



PE: Protective Earth

Note:

- Change the direction of single-phase motor rotation only after bringing the motor to a stop.
If an attempt is made to change the direction of rotation while the motor is rotating, motor may ignore reversing command or change its direction of rotation after some delay.
- How to connect a capacitor → Page A-313

Accessories and Peripheral Equipment

(Instantaneous Stop
Brake Pack
→Page A-277)(Accessories
→Page A-287)

Induction Motors

6 W (1/125 HP)

Frame Size: □60 mm (□2.36 in.)



(Gearhead sold separately)

■ Specifications – Continuous Rating (RoHS)



Model Lead Wire Type		Output Power W HP	Voltage VAC	Frequency Hz	Current A	Starting Torque mN·m oz-in	Rated Torque mN·m oz-in	Rated Speed r/min	Capacitor μF
Pinion Shaft Type	Round Shaft Type								
ZP 2IK6GN-AW2U	2IK6A-AW2U	6 1/125	Single-Phase 110	60	0.178	40	41	1450	2.5
			Single-Phase 115		0.182	5.6	5.8		
ZP 2IK6GN-CW2E	2IK6A-CW2E	6 1/125	Single-Phase 220	50	0.103	38 5.3	49 6.9	1150	0.6
				60	0.091	40 5.6	41 5.8	1450	
			Single-Phase 230	50	0.107	45 6.3	49 6.9	1200	
				60	0.094	40 5.6	41 5.8	1450	
			Three-Phase 200	50	0.081	49 6.9	49 6.9	1200	—
				60	0.072	41 5.8	41 5.8	1400	
			Three-Phase 220	60	0.076	41 5.8	41 5.8	1500	
			Three-Phase 230	60	0.079	41 5.8	41 5.8	1500	

● The **U** and **E** at the end of the model name indicate that the unit includes a capacitor. These letters are not listed on the motor nameplate. When the motor is approved under various safety standards, the model name on the nameplate is the approved model name. → Page G-11

● Details of safety standards → Page G-2

● Details of RoHS Directive → Page G-38

ZP: Impedance protected

■ Product Line

● Motor (RoHS)

Type	Model	
	Pinion Shaft Type	Round Shaft Type
	2IK6GN-AW2U	2IK6A-AW2U
Lead Wire	2IK6GN-CW2E	2IK6A-CW2E
	2IK6GN-SW2	2IK6A-SW2

The following items are included in each product.

Motor, Capacitor*, Capacitor Cap*, Operating Manual

* Only for single-phase motors

● Parallel Shaft Gearhead (Sold separately) (RoHS)

Gearhead Type	Gearhead Model	Gear Ratio
Parallel Shaft	Long Life, Low Noise GN-S Gearhead	3, 3.6, 5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180
		2GN10XS (Decimal Gearhead)

● Enter the gear ratio in the box (□) within the model name.

The following items are included in each product.

Gearhead, Mounting Screws, Operating Manual

● Following gearheads are also available. For details, please refer to website (<http://www.orientalmotor.com/>) or contact the nearest Oriental Motor sales office.

Gearhead Type	Gearhead Model	Gear Ratio
Parallel Shaft	GN-K Gearhead	2GN□KA
		2GN10XK (Decimal Gearhead)

● Enter the gear ratio in the box (□) within the model name.

Gearmotor – Torque Table

- Gearheads and decimal gearheads are sold separately.
- Enter the gear ratio in the box (□) within the gearhead model name.
- A colored background (■) indicates gear shaft rotation in the same direction as the motor shaft, while the others rotate in the opposite direction.
- The speed is calculated by dividing the motor's synchronous speed (50 Hz: 1500 r/min, 60 Hz: 1800 r/min) by the gear ratio.
The actual speed is 2~20% less than the displayed value, depending on the load.
- To reduce the speed beyond the gear ratio in the table, attach a decimal gearhead (gear ratio 10:1) between the gearhead and the motor.
In that case, the permissible torque is 3 N·m (26 lb-in).

◇ 50 Hz

Unit = Upper values: N·m/Lower values: lb-in

Model Motor/ Gearhead	Speed r/min	500	416	300	250	200	166	120	100	83	60	50	41	30	25	20	16	15	12.5	10	8.3
	Gear Ratio	3	3.6	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150	180
2IK6GN-CW2E	2GN□SA	0.12 1.06	0.14 1.23	0.20 1.77	0.24 2.1	0.30 2.6	0.36 3.1	0.50 4.4	0.60 5.3	0.71 6.2	0.89 7.8	1.1 9.7	1.3 11.5	1.6 14.1	1.9 16.8	2.4 21	2.9 25	3 26	3 26	3 26	3 26
2IK6GN-SW2																					

◇ 60 Hz

Unit = Upper values: N·m/Lower values: lb-in

Model Motor/ Gearhead	Speed r/min	600	500	360	300	240	200	144	120	100	72	60	50	36	30	24	20	18	15	12	10
	Gear Ratio	3	3.6	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150	180
2IK6GN-AW2U	2GN□SA	0.10 0.88	0.12 1.06	0.17 1.50	0.20 1.77	0.25 2.2	0.30 2.6	0.42 3.7	0.50 4.4	0.60 5.3	0.75 6.6	0.90 7.9	1.1 9.7	1.4 12.3	1.6 14.1	2.0 17.7	2.4 21	2.7 23	3 26	3 26	3 26
2IK6GN-CW2E																					
2IK6GN-SW2																					

Permissible Overhung Load and Permissible Thrust Load

Motor (Round shaft type) → Page A-16

Gearhead → Page A-16

Permissible Load Inertia J of Gearhead


→ Page A-17

Dimensions Unit = mm (in.)

● Mounting screws are included with gearheads. Dimensions for mounting screws → Page A-310


◊ Lead Wire Type

Mass: Motor 0.7 kg (1.54 lb.)
Gearhead 0.4 kg (0.88 lb.)



Motor Model	Gearhead Model	Gear Ratio	L	DXF
2IK6GN-AW2U 2IK6GN-CW2E 2IK6GN-SW2	2GN□SA	3~18	30 (1.18)	A443AU
		25~180	40 (1.57)	A443BU

● Enter the gear ratio in the box (□) within the model name.




Detail Drawing of Protective Earth Terminal

◊ Shaft Section of Round Shaft Type



The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.

Motor Model	Mass	DXF
2IK6A-AW2U	0.7 kg	
2IK6A-CW2E	(1.54 lb.)	
2IK6A-SW2	A444	



◊ Capacitor

Included with single-phase motors)




◊ Decimal Gearhead

Can be connected to **GN** pinion shaft type.

2GN10XS

Mass: 0.2 kg (0.44 lb.)

DXF A003




◊ Capacitor Dimensions Unit = mm (in.)

Model		Capacitor Model	A	B	C	Mass g (oz.)	Capacitor Cap
Pinion Shaft Type	Round Shaft Type						
2IK6GN-AW2U	2IK6A-AW2U	CH25FAUL2	31 (1.22)	17 (0.67)	27 (1.06)	21 (0.74)	Included
2IK6GN-CW2E	2IK6A-CW2E	CH06BFAUL	31 (1.22)	14.5 (0.57)	23.5 (0.93)	18 (0.64)	

■ Connection Diagrams


- The direction of motor rotation is as viewed from the shaft end of the motor. CW represents the clockwise direction, while CCW represents the counterclockwise direction.
- Connection diagrams are also valid for the equivalent round shaft type.



PE: Protective Earth

Note:

- Change the direction of single-phase motor rotation only after bringing the motor to a stop. If an attempt is made to change the direction of rotation while the motor is rotating, motor may ignore reversing command or change its direction of rotation after some delay.
- How to connect a capacitor → Page A-313



Induction Motors

15 W (1/50 HP)

Frame Size: □70 mm (□2.76 in.)



(Gearhead sold separately)



Specifications – Continuous Rating (RoHS)

Model Lead Wire Type		Output Power W HP	Voltage VAC	Frequency Hz	Current A	Starting Torque mN·m oz-in	Rated Torque mN·m oz-in	Rated Speed r/min	Capacitor μF	
Pinion Shaft Type	Round Shaft Type									
(TP) 3IK15GN-AW2U	3IK15A-AW2U	15 1/50	Single-Phase 110	60	0.33	65	105	1450	4.5	
			Single-Phase 115		0.34	9.2	14.9			
		15 1/50	Single-Phase 220	50	0.19	70 9.9	125 17.7	1200	1.0	
				60	0.16	65 9.2	105 14.9			
			Single-Phase 230	50	0.19	75 10.6	125 17.7	1200		
				60	0.16	65 9.2	105 14.9			

● The **U** and **E** at the end of the model name indicate that the unit includes a capacitor. These letters are not listed on the motor nameplate.

When the motor is approved under various safety standards, the model name on the nameplate is the approved model name. → Page G-11

● Details of safety standards → Page G-2

● Details of RoHS Directive → Page G-38

(TP): Contains a built-in thermal protector (automatic return type). If a motor overheats for any reason, the thermal protector is activated and the motor is stopped.

When the motor temperature drops, the thermal protector closes and the motor restarts. Be sure to turn the motor power off before inspecting.

Product Line

Motor (RoHS)

Type	Model	
	Pinion Shaft Type	Round Shaft Type
Lead Wire	3IK15GN-AW2U	3IK15A-AW2U
	3IK15GN-CW2E	3IK15A-CW2E

The following items are included in each product.

Motor, Capacitor, Capacitor Cap, Operating Manual

Parallel Shaft Gearhead (Sold separately) (RoHS)

Gearhead Type		Gearhead Model	Gear Ratio
Parallel Shaft	Long Life, Low Noise GN-S Gearhead	3GN□SA	3, 3.6, 5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180

3GN10XS (Decimal Gearhead)

● Enter the gear ratio in the box (□) within the model name.

The following items are included in each product.

Gearhead, Mounting Screws, Operating Manual

● Following gearheads are also available. For details, please refer to website (<http://www.orientalmotor.com/>) or contact the nearest Oriental Motor sales office.

Gearhead Type		Gearhead Model	Gear Ratio
Parallel Shaft	<small>(RoHS)</small> GN-K Gearhead	3GN□KA	3~180


3GN10XK (Decimal Gearhead)

● Enter the gear ratio in the box (□) within the model name.


◇ Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.

Motor Model	Mass	DXF
3IK15A-AW2U	1.1 kg (2.4 lb.)	A448
3IK15A-CW2E		



◇ Capacitor (Included)




◇ Decimal Gearhead

Can be connected to **GN** pinion shaft type.

3GN10XS

Mass: 0.3 kg (0.66 lb.)

DXF A009




◇ Capacitor Dimensions Unit = mm (in.)

Model		Capacitor Model	A	B	C	Mass g (oz.)	Capacitor Cap
Pinion Shaft Type	Round Shaft Type						
3IK15GN-AW2U	3IK15A-AW2U	CH45FAUL2	37 (1.46)	18 (0.71)	27 (1.06)	26 (0.92)	Included
3IK15GN-CW2E	3IK15A-CW2E	CH10BFAUL	37 (1.46)	18 (0.71)	27 (1.06)	27 (0.95)	

Connection Diagrams

- The direction of motor rotation is as viewed from the shaft end of the motor. CW represents the clockwise direction, while CCW represents the counterclockwise direction.
- Connection diagrams are also valid for the equivalent round shaft type.

3IK15GN-AW2U 3IK15GN-CW2E



PE: Protective Earth

Note:

- Change the direction of single-phase motor rotation only after bringing the motor to a stop. If an attempt is made to change the direction of rotation while the motor is rotating, motor may ignore reversing command or change its direction of rotation after some delay.
- How to connect a capacitor → Page A-313

Accessories and Peripheral Equipment

Instantaneous Stop
Brake Pack

→ Page A-277

Accessories


→ Page A-287



Induction Motors

25 W (1/30 HP)

Frame Size: □80 mm (□3.15 in.)

Terminal Box Type
(Gearhead sold separately)

■ Specifications – Continuous Rating (RoHS)

Model Upper Model Name: Pinion Shaft Type Lower Model Name (): Round Shaft Type			Output Power W HP	Voltage VAC	Frequency Hz	Current A	Starting Torque mN·m oz-in	Rated Torque mN·m oz-in	Rated Speed r/min	Capacitor μF			
Lead Wire Type Dimension ①	Terminal Box Type Dimension ②	Conduit Box Type Dimension ③											
(TP) 4IK25GN-AW2U (4IK25A-AW2U)	4IK25GN-AW2TU (4IK25A-AW2TU)	4IK25GN-FCH (4IK25AA-FCH)	25 1/30	Single-Phase 110	60	0.46	120 17.0	170 24	1450	6.5			
(TP) 4IK25GN-CW2E (4IK25A-CW2E)	4IK25GN-CW2TE (4IK25A-CW2TE)	4IK25GN-ECH (4IK25AA-ECH)											
		Single-Phase 220		50	0.27	110 15.6	205 29	1200					
				60	0.23								
		Single-Phase 230		50	0.27	120 17.0	205 29	1200					
				60	0.23								
		Single-Phase 220		60	0.22	120 17.0	170 24	1450	1.5				
				50	0.24								
				60	0.22								
		Three-Phase 200	Single-Phase 230	50	0.23	120 17.0	205 29	1200					
				60	0.21								
			Three-Phase 220	60	0.21	160 22	160 22	1550					
				60	0.22								
		Three-Phase 230	4IK25GN-SH (4IK25AA-SH)	50	0.23	160 22	160 22	1600					
				60	0.21								
				60	0.22								

● The **U** and **E** at the end of the model name indicate that the unit includes a capacitor. These letters are not listed on the motor nameplate.
When the motor is approved under various safety standards, the model name on the nameplate is the approved model name. → Page G-11

● Details of safety standards → Page G-2

● Details of RoHS Directive → Page G-38

* Conduit box type is not certified under the China Compulsory Certification System (CCC System).

(TP): Contains a built-in thermal protector (automatic return type). If a motor overheats for any reason, the thermal protector is activated and the motor is stopped.
When the motor temperature drops, the thermal protector closes and the motor restarts. Be sure to turn the motor power off before inspecting.

■ Product Line

● Motor (RoHS)

Type	Model	
	Pinion Shaft Type	Round Shaft Type
Lead Wire	4IK25GN-AW2U	4IK25A-AW2U
	4IK25GN-CW2E	4IK25A-CW2E
	4IK25GN-SW2	4IK25A-SW2
Terminal Box	4IK25GN-AW2TU	4IK25A-AW2TU
	4IK25GN-CW2TE	4IK25A-CW2TE
	4IK25GN-SW2T	4IK25A-SW2T
Conduit Box	4IK25GN-FCH	4IK25AA-FCH
	4IK25GN-ECH	4IK25AA-ECH
	4IK25GN-SH	4IK25AA-SH

The following items are included in each product.

Motor, Capacitor*, Capacitor Cap*, Operating Manual

* Only for single-phase motors (Excluding conduit box type)

● Parallel Shaft Gearhead/Right-Angle Gearhead

(Sold separately)

Gearhead Type		Gearhead Model	Gear Ratio
Parallel Shaft	Long Life, Low Noise GN-S Gearhead	4GN□SA	3, 3.6, 5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180
Right-Angle Shaft	Hollow Shaft	4GN□RH	
	Solid Shaft	4GN□RAA	
Parallel Shaft	Long Life, Low Noise GN-S Gearhead	4GN10XS (Decimal Gearhead)	

● Enter the gear ratio in the box (□) within the model name.

The following items are included in each product.

- Parallel Shaft Gearhead
Gearhead, Mounting Screws, Operating Manual
- Hollow Shaft Gearhead
Gearhead, Mounting Screws, Parallel Key, Safety Cover (with screws), Gasket, Operating Manual
- Solid Shaft Gearhead
Gearhead, Mounting Screws, Gasket, Operating Manual

● Following gearheads are also available. For details, please refer to website (<http://www.orientalmotor.com/>) or contact the nearest Oriental Motor sales office.

Gearhead Type		Gearhead Model	Gear Ratio
Parallel Shaft	GN-K Gearhead	4GN□KA	3~180
		4GN10XK (Decimal Gearhead)	

● Enter the gear ratio in the box (□) within the model name.

■ Gearmotor – Torque Table

- Gearheads and decimal gearheads are sold separately.
- Enter the code that represents the terminal box type "T" in the box (□) within the motor model name.
- Enter the gear ratio in the box (□) within the gearhead model name.
- A colored background (□) indicates gear shaft rotation in the same direction as the motor shaft, while the others rotate in the opposite direction.
- The speed is calculated by dividing the motor's synchronous speed (50 Hz: 1500 r/min, 60 Hz: 1800 r/min) by the gear ratio.
The actual speed is 2~20% less than the displayed value, depending on the load.
- To reduce the speed beyond the gear ratio in the table, attach a decimal gearhead (gear ratio 10:1) between the gearhead and the motor.
In that case, the permissible torque is 8 N·m (70 lb-in). When a gearhead of 25:1~36:1 is connected, the value for permissible torque is 6 N·m (53 lb-in).

◇ 50 Hz

Model	Speed r/min	500	416	300	250	200	166	120	100	83	60	50	41	30	25	20	16	15	12.5	10	8.3	
	Motor/ Gearhead	Gear Ratio	3	3.6	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150	180
4IK25GN-CW2□E	4GN□SA	0.50	0.60	0.83	1.0	1.2	1.5	2.1	2.5	3.0	3.7	4.5	5.4	6.8	8	8	8	8	8	8	8	8
4IK25GN-ECH		4.4	5.3	7.3	8.8	10.6	13.2	18.5	22	26	32	39	47	60	70	70	70	70	70	70	70	70
4IK25GN-SW2□	4GN□SA	0.46	0.55	0.77	0.92	1.2	1.4	1.9	2.3	2.8	3.5	4.2	5.0	6.3	7.5	8	8	8	8	8	8	8
4IK25GN-SH		4.0	4.8	6.8	8.1	10.6	12.3	16.8	20	24	30	37	44	55	66	70	70	70	70	70	70	70

◇ 60 Hz

Model	Speed r/min	600	500	360	300	240	200	144	120	100	72	60	50	36	30	24	20	18	15	12	10	
	Motor/ Gearhead	Gear Ratio	3	3.6	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150	180
4IK25GN-AW2□U	4GN□SA	0.41	0.50	0.69	0.83	1.0	1.2	1.7	2.1	2.5	3.1	3.7	4.5	5.6	6.7	8	8	8	8	8	8	8
4IK25GN-CW2□E		3.6	4.4	6.1	7.3	8.8	10.6	15.0	18.5	22	27	32	39	49	59	70	70	70	70	70	70	70
4IK25GN-FCH																						
4IK25GN-ECH																						
4IK25GN-SW2□	4GN□SA	0.39	0.47	0.65	0.78	0.97	1.2	1.6	1.9	2.3	2.9	3.5	4.2	5.3	6.3	7.9	8	8	8	8	8	8
4IK25GN-SH		3.4	4.1	5.7	6.9	8.5	10.6	14.1	16.8	20	25	30	37	46	55	69	70	70	70	70	70	70

Unit = Upper values: N·m/ Lower values: lb-in

■ Gearmotor – Torque Table When Right-Angle Gearhead is Attached

→ Page A-248

■ Permissible Overhung Load and Permissible Thrust Load

Motor (Round shaft type) → Page A-16

Gearhead → Page A-16

■ Permissible Load Inertia J of Gearhead


→ Page A-17

Dimensions Unit = mm (in.)

● Mounting screws are included with gearheads. Dimensions for mounting screws → Page A-310


◇ Lead Wire Type ①

Mass: Motor 1.5 kg (3.3 lb.)
Gearhead 0.65 kg (1.43 lb.)



Motor Model	Gearhead Model	Gear Ratio	L	DXF
4IK25GN-AW2U 4IK25GN-CW2E 4IK25GN-SW2	4GN□SA	3~18	32 (1.26)	A449AU
		25~180	42.5 (1.67)	A449BU


● Enter the gear ratio in the box (□) within the model name.



Detail Drawing of Protective Earth Terminal

◇ Terminal Box Type ②

Mass: Motor 1.7 kg (3.7 lb.)
Gearhead 0.65 kg (1.43 lb.)




● Use cable with a diameter of φ6 ~ φ12 mm (φ0.24 ~ φ0.47 in.).

● Details of terminal box → Page A-314

◇ Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.



Motor Model	Gearhead Model	Gear Ratio	L	DXF
4IK25GN-AW2TU 4IK25GN-CW2TE 4IK25GN-SW2T	4GN□SA	3~18	32 (1.26)	A451AU
		25~180	42.5 (1.67)	A451BU

● Enter the gear ratio in the box (□) within the model name.


Motor Model	Mass	DXF
4IK25A-AW2U 4IK25A-CW2E 4IK25A-SW2	1.5 kg (3.3 lb.)	A450
4IK25A-AW2TU 4IK25A-CW2TE 4IK25A-SW2T	1.7 kg (3.7 lb.)	A328

◇Conduit Box Type ③

Motor Model	Gearhead Model	Gear Ratio	L	DXF
4IK25GN-FCH	4GN□SA	3~18	32 (1.26)	A900AU
4IK25GN-ECH		25~180	42.5 (1.67)	A900BU

Mass: Motor 1.9 kg (4.2 lb.)

Gearhead 0.65 kg (1.43 lb.)



3 Motor Leads: UL Style 3266, AWG20

1 Ground Lead: UL Style 3266, AWG18


● Details of terminal box → Page A-314

● Enter the gear ratio in the box (□) within the model name.

Motor Model	Gearhead Model	Gear Ratio	L	DXF
4IK25GN-SH	4GN□SA	3~18	32 (1.26)	A901AU
		25~180	42.5 (1.67)	A901BU

Mass: Motor 1.7 kg (3.7 lb.)

Gearhead 0.65 kg (1.43 lb.)



3 Motor Leads: UL Style 3266, AWG20

1 Ground Lead: UL Style 3266, AWG18


● Details of terminal box → Page A-314

● Enter the gear ratio in the box (□) within the model name.

◇Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.


Motor Model	Mass	DXF
4IK25AA-FCH	1.9 kg (4.2 lb.)	A809
4IK25AA-ECH		



◇Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.

Motor Model	Mass	DXF
4IK25AA-SH	1.7 kg (3.7 lb.)	A810




◇ Decimal Gearhead

Can be connected to **GN** pinion shaft type.

4GN10XS


Mass: 0.4 kg (0.88 lb.)

DXF A013



◇ Capacitor

(Included with single-phase motors)




◇ Capacitor Dimensions Unit = mm (in.)

Model		Capacitor Model	A	B	C	Mass g (oz.)	Capacitor Cap
Upper Model Name: Pinion Shaft Type	Lower Model Name (): Round Shaft Type						
4IK25GN-AW2U (4IK25A-AW2U)	4IK25GN-AW2TU (4IK25A-AW2TU)	CH65CFAUL2	48 (1.89)	19 (0.75)	29 (1.14)	35 (1.24)	Included
4IK25GN-CW2E (4IK25A-CW2E)	4IK25GN-CW2TE (4IK25A-CW2TE)	CH15BFAUL	38 (1.50)	21 (0.83)	31 (1.22)	37 (1.31)	

■ Connection Diagrams




- The direction of motor rotation is as viewed from the shaft end of the motor. CW represents the clockwise direction, while CCW represents the counterclockwise direction.
- Connection diagrams are also valid for the equivalent round shaft type.



PE: Protective Earth

Note:

- Change the direction of single-phase motor rotation only after bringing the motor to a stop.
If an attempt is made to change the direction of rotation while the motor is rotating, motor may ignore reversing command or change its direction of rotation after some delay.
- How to connect a capacitor → Page A-313

Conduit Box Type	
4IK25GN-FCH 4IK25GN-ECH	4IK25GN-SH
Clockwise  <p>*NC: No connection</p>	Clockwise 
Counterclockwise  <p>*NC: No connection</p>	Counterclockwise To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).

PE: Protective Earth

Note:

- Change the direction of single-phase motor rotation only after bringing the motor to a stop.
If an attempt is made to change the direction of rotation while the motor is rotating, motor may ignore reversing command or change its direction of rotation after some delay.
- How to connect a capacitor → Page A-313

Gearhead, Accessories and Peripheral Equipment

(Space-Saving)
Right-Angle Gearheads
→ Page A-239



(Instantaneous Stop)
Brake Pack
→ Page A-277



(Speed Control)
Speed Controller
→ Page B-156



(Accessories)
→ Page A-287



Induction Motors

40 W (1/19 HP)

Frame Size: □90 mm (□3.54 in.)

Terminal Box Type
(Gearhead sold separately)

Specifications – Continuous Rating (RoHS)

Model Upper Model Name: Pinion Shaft Type Lower Model Name (): Round Shaft Type			Output Power W HP	Voltage VAC	Frequency Hz	Current A	Starting Torque mN·m oz-in	Rated Torque mN·m oz-in	Rated Speed r/min	Capacitor μF
Lead Wire Type Dimension ①	Terminal Box Type Dimension ②	Conduit Box Type Dimension ③								
TP 5IK40GN-AW2U (5IK40A-AW2U)	5IK40GN-AW2TU (5IK40A-AW2TU)	5IK40GN-FCH (5IK40AA-FCH)	40 1/19	Single-Phase 110 Single-Phase 115	60 0.67	0.68 0.67	200 28	260 36	1500	9.0
TP 5IK40GN-CW2E (5IK40A-CW2E)	5IK40GN-CW2TE (5IK40A-CW2TE)	5IK40GN-ECH ^{*1} (5IK40AA-ECH) ^{*1}	40 1/19	Single-Phase 220 Single-Phase 230	50 60 50 60	0.39 0.35 0.39 0.34	200 28	315 44 260 36 300 42 260 36	1250 1500 1300 1500	2.3
TP 5IK40GN-SW2 (5IK40A-SW2)	5IK40GN-SW2T (5IK40A-SW2T)	5IK40GN-SH (5IK40AA-SH)	40 1/19	Three-Phase 200 Three-Phase 220 Three-Phase 230	50 60 60 60	0.32 0.30 0.30 0.31	400 260 260 260	300 42 36 36	1300 1550 1600 1600	—

● The **U** and **E** at the end of the model name indicate that the unit includes a capacitor. These letters are not listed on the motor nameplate.
When the motor is approved under various safety standards, the model name on the nameplate is the approved model name. → Page G-11

● Details of safety standards → Page G-2 ● Details of RoHS Directive → Page G-38

*1 Single-Phase 220 VAC 50Hz type is not available for conduit box type.

*2 Conduit box type is not certified under the China Compulsory Certification System (CCC System).

TP: Contains a built-in thermal protector (automatic return type). If a motor overheats for any reason, the thermal protector is activated and the motor is stopped.
When the motor temperature drops, the thermal protector closes and the motor restarts. Be sure to turn the motor power off before inspecting.

Product Line

● Motor (RoHS)

Type	Model	
	Pinion Shaft Type	Round Shaft Type
Lead Wire	5IK40GN-AW2U	5IK40A-AW2U
	5IK40GN-CW2E	5IK40A-CW2E
Terminal Box	5IK40GN-SW2	5IK40A-SW2
	5IK40GN-AW2TU	5IK40A-AW2TU
Conduit Box	5IK40GN-CW2TE	5IK40A-CW2TE
	5IK40GN-SW2T	5IK40A-SW2T
Conduit Box	5IK40GN-FCH	5IK40AA-FCH
	5IK40GN-ECH	5IK40AA-ECH
	5IK40GN-SH	5IK40AA-SH

The following items are included in each product.

Motor, Capacitor*, Capacitor Cap*, Operating Manual

* Only for single-phase motors (Excluding conduit box type)

● Parallel Shaft Gearhead/Right-Angle Gearhead (Sold separately) (RoHS)

Gearhead Type		Gearhead Model	Gear Ratio
Parallel Shaft	Long Life, Low Noise GN-S Gearhead	5GN□SA	3, 3.6, 5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180
	Hollow Shaft	5GN□RH	
	Solid Shaft	5GN□RAA	
Parallel Shaft	Long Life, Low Noise GN-S Gearhead	5GN10XS (Decimal Gearhead)	

● Enter the gear ratio in the box (□) within the model name.

— The following items are included in each product. —

● Parallel Shaft Gearhead

Gearhead, Mounting Screws, Operating Manual

● Hollow Shaft Gearhead

Gearhead, Mounting Screws, Parallel Key, Safety Cover (with screws), Gasket, Operating Manual

● Solid Shaft Gearhead

Gearhead, Mounting Screws, Gasket, Operating Manual

● Following gearheads are also available. For details, please refer to website (<http://www.orientalmotor.com/>) or contact the nearest Oriental Motor sales office.

Gearhead Type		Gearhead Model	Gear Ratio
Parallel Shaft	(RoHS) GN-K Gearhead	5GN□KA	3~180
		5GN10XK (Decimal Gearhead)	

● Enter the gear ratio in the box (□) within the model name.

Gearmotor – Torque Table

- Gearheads and decimal gearheads are sold separately.
- Enter the code that represents the terminal box type "T" in the box (□) within the motor model name.
- Enter the gear ratio in the box (□) within the gearhead model name.
- A colored background (■) indicates gear shaft rotation in the same direction as the motor shaft, while the others rotate in the opposite direction.
- The speed is calculated by dividing the motor's synchronous speed (50 Hz: 1500 r/min, 60 Hz: 1800 r/min) by the gear ratio.
The actual speed is 2~20% less than the displayed value, depending on the load.
- To reduce the speed beyond the gear ratio in the table, attach a decimal gearhead (gear ratio 10:1) between the gearhead and the motor.
In that case, the permissible torque is 10 N·m (88 lb-in).

◇ 50 Hz

Unit = Upper values: N·m/Lower values: lb-in

Model Motor/ Gearhead	Speed r/min	500	416	300	250	200	166	120	100	83	60	50	41	30	25	20	16	15	12.5	10	8.3
	Gear Ratio	3	3.6	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150	180
5IK40GN-CW2■E (Single-phase 220 VAC)	5GN□SA	0.77 6.8	0.92 8.1	1.3 11.5	1.5 13.2	1.9 16.8	2.3 20	3.2 28	3.8 33	4.6 40	5.7 50	6.9 61	8.3 73	10 88	10 88	10 88	10 88	10 88	10 88	10 88	10 88
5IK40GN-CW2■E 5IK40GN-ECH (Single-phase 230 VAC) 5IK40GN-SW2■ 5IK40GN-SH	5GN□SA	0.73 6.4	0.87 7.6	1.2 10.6	1.5 13.2	1.8 15.9	2.2 19.4	3.0 26	3.6 31	4.4 38	5.5 48	6.6 58	7.9 69	9.9 87	10 88						

◇ 60 Hz

Unit = Upper values: N·m/Lower values: lb-in

Model Motor/ Gearhead	Speed r/min	600	500	360	300	240	200	144	120	100	72	60	50	36	30	24	20	18	15	12	10
	Gear Ratio	3	3.6	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150	180
5IK40GN-AW2■U 5IK40GN-CW2■E 5IK40GN-SW2■ 5IK40GN-FCH 5IK40GN-ECH 5IK40GN-SH	5GN□SA	0.63 5.5	0.76 6.7	1.1 9.7	1.3 11.5	1.6 14.1	1.9 16.8	2.6 23	3.2 28	3.8 33	4.7 41	5.7 50	6.8 60	8.6 76	10 88						

Gearmotor – Torque Table When Right-Angle Gearhead is Attached

→ Page A-248

Permissible Overhung Load and Permissible Thrust Load

Motor (Round shaft type) → Page A-16

Gearhead → Page A-16

Permissible Load Inertia J of Gearhead

→ Page A-17


Dimensions Unit = mm (in.)

- Mounting screws are included with gearheads. Dimensions for mounting screws → Page A-310

Lead Wire Type ①


Mass: Motor 2.5 kg (5.5 lb.)

Gearhead 1.5 kg (3.3 lb.)



Motor Model	Gearhead Model	Gear Ratio	L	DXF
5IK40GN-AW2U 5IK40GN-CW2E 5IK40GN-SW2	5GN□SA	3~18	42 (1.65)	A452AU
		25~180	60 (2.36)	A452BU

● Enter the gear ratio in the box (□) within the model name.




Detail Drawing of Protective Earth Terminal

◆ Terminal Box Type ②

Mass: Motor 2.6 kg (5.7 lb.)
Gearhead 1.5 kg (3.3 lb.)

Motor Model	Gearhead Model	Gear Ratio	L	DXF
5IK40GN-AW2TU	5GN□SA	3~18	42 (1.65)	A454AU
5IK40GN-CW2TE				
5IK40GN-SW2T		25~180	60 (2.36)	A454BU

- Enter the gear ratio in the box (□) within the model name.




- Use cable with a diameter of $\phi 6 \sim \phi 12$ mm ($\phi 0.24 \sim \phi 0.47$ in.).
 - Details of terminal box → Page A-314

◇Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.


Motor Model	Mass	DXF
5IK40A-AW2U	2.5 kg (5.5 lb.)	A453
5IK40A-CW2E		
5IK40A-SW2		
5IK40A-AW2TU	2.6 kg (5.7 lb.)	A330
5IK40A-CW2TE		
5IK40A-SW2T		



◇ Conduit Box Type ③

Motor Model	Gearhead Model	Gear Ratio	L	DXF
5IK40GN-FCH	5GN□SA	3~18	42 (1.65)	A902AU
5IK40GN-ECH		25~180	60 (2.36)	A902BU


Mass: Motor 2.7 kg (5.9 lb.)
Gearhead 1.5 kg (3.3 lb.)



3 Motor Leads: UL Style 3266, AWG20
1 Ground Lead: UL Style 3266, AWG18
● Details of terminal box → Page A-314

Motor Model	Gearhead Model	Gear Ratio	L	DXF
5IK40GN-SH	5GN□SA	3~18	42 (1.65)	A903AU
		25~180	60 (2.36)	A903BU

Mass: Motor 2.5 kg (5.5 lb.)
Gearhead 1.5 kg (3.3 lb.)




3 Motor Leads: UL Style 3266, AWG20
1 Ground Lead: UL Style 3266, AWG18
● Details of terminal box → Page A-314

◇ Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.


Motor Model	Mass	DXF
5IK40AA-FCH	2.7 kg (5.9 lb.)	A811
5IK40AA-ECH		



◇ Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.

Motor Model	Mass	DXF
5IK40AA-SH	2.5 kg (5.5 lb.)	A812




◇ Decimal Gearhead

Can be connected to **GN** pinion shaft type.

5GN10XS


Mass: 0.6 kg (1.32 lb.)

DXF A022



◇ Capacitor

(Included with single-phase motors)



◇ Capacitor Dimensions Unit = mm (in.)

Model		Capacitor Model	A	B	C	Mass g (oz.)	Capacitor Cap
Upper Model Name: Pinion Shaft Type	Lower Model Name (:): Round Shaft Type						
5IK40GN-AW2U (5IK40A-AW2U)	5IK40GN-AW2TU (5IK40A-AW2TU)	CH90CFAUL2	48 (1.89)	22.5 (0.89)	31.5 (1.24)	45 (1.59)	Included
5IK40GN-CW2E (5IK40A-CW2E)	5IK40GN-CW2TE (5IK40A-CW2TE)						

■ Connection Diagrams




- The direction of motor rotation is as viewed from the shaft end of the motor. CW represents the clockwise direction, while CCW represents the counterclockwise direction.
- Connection diagrams are also valid for the equivalent round shaft type.

Lead Wire Type		Terminal Box Type	
5IK40GN-AW2U 5IK40GN-CW2E	5IK40GN-SW2	5IK40GN-AW2TU 5IK40GN-CW2TE	5IK40GN-SW2T
Clockwise	Clockwise	Clockwise	Clockwise
<p>White, Red, Black wires connect to the motor. A capacitor is connected between the motor and PE.</p>	<p>L1(R), L2(S), L3(T) wires connect to the motor. A capacitor is connected between the motor and PE.</p>	<p>L, N wires connect to the motor. A capacitor is connected between the motor and PE.</p>	<p>L1(R), L2(S), L3(T) wires connect to the motor. A capacitor is connected between the motor and PE.</p>
Counterclockwise	Counterclockwise	Counterclockwise	Counterclockwise
<p>White, Red, Black wires connect to the motor. A capacitor is connected between the motor and PE.</p>	<p>L1(R), L2(S), L3(T) wires connect to the motor. A capacitor is connected between the motor and PE.</p>	<p>L, N wires connect to the motor. A capacitor is connected between the motor and PE.</p>	<p>L1(R), L2(S), L3(T) wires connect to the motor. A capacitor is connected between the motor and PE.</p>

PE: Protective Earth

Note:

- Change the direction of single-phase motor rotation only after bringing the motor to a stop. If an attempt is made to change the direction of rotation while the motor is rotating, motor may ignore reversing command or change its direction of rotation after some delay.
- How to connect a capacitor → Page A-313

Conduit Box Type	
5IK40GN-FCH 5IK40GN-ECH	5IK40GN-SH
Clockwise  <p>*NC: No connection</p>	Clockwise 
Counterclockwise  <p>*NC: No connection</p>	Counterclockwise To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).

PE: Protective Earth

Note:

- Change the direction of single-phase motor rotation only after bringing the motor to a stop.
If an attempt is made to change the direction of rotation while the motor is rotating, motor may ignore reversing command or change its direction of rotation after some delay.
- How to connect a capacitor → Page A-313

Gearhead, Accessories and Peripheral Equipment

(Space-Saving)
Right-Angle Gearheads
→ Page A-239



(Instantaneous Stop)
Brake Pack
→ Page A-277



(Speed Control)
Speed Controller
→ Page B-156



(Accessories)
→ Page A-287



Induction Motors

60 W (1/12 HP)

Frame Size: □90 mm (□3.54 in.)

Terminal Box Type
(Gearhead sold separately)1 W, 3 W
(1/750 HP,
1/250 HP)6 W
(1/125 HP)15 W
(1/50 HP)25 W
(1/30 HP)40 W
(1/19 HP)60 W
(1/12 HP)90 W
(1/8 HP)200 W
(1/4 HP)2-Pole
40-50 W
(1/19-1/5 HP)

Specifications – Continuous Rating (RoHS)

Model Upper Model Name: Pinion Shaft Type Lower Model Name (): Round Shaft Type			Output Power W HP	Voltage VAC	Frequency Hz	Current A	Starting Torque mN·m oz-in	Rated Torque mN·m oz-in	Rated Speed r/min	Capacitor μF
Lead Wire Type Dimension ①	Terminal Box Type Dimension ②	Conduit Box Type Dimension ③								
TP 5IK60GE-AW2U (5IK60A-AW2U)	5IK60GE-AW2TU (5IK60A-AW2TU)	5IK60GE-FCH (5IK60A-FCH)	60 1/12	Single-Phase 110 Single-Phase 115	60	1.09 1.10	320 45	405 57	1450	18
TP 5IK60GE-CW2E (5IK60A-CW2E)	5IK60GE-CW2TE (5IK60A-CW2TE)	5IK60GE-ECH^{*1} (5IK60A-ECH) ^{*1}	60 1/12	Single-Phase 220	50	0.55	320 45	490 69	1200	4.0
					60	0.54		405 57	1450	
				Single-Phase 230	50	0.57		490 69	1200	
					60	0.54		405 57	1450	
			60 1/12	Three-Phase 200	50	0.50	600 85	450 63	1300	—
					60	0.43	500 71	380 53	1550	
				Three-Phase 220	60	0.45	500 71	380 53	1600	
				Three-Phase 230	60	0.46	500 71	380 53	1600	

- The **U** and **E** at the end of the model name indicate that the unit includes a capacitor. These letters are not listed on the motor nameplate. When the motor is approved under various safety standards, the model name on the nameplate is the approved model name. → Page G-11

- Details of safety standards → Page G-2

- Details of RoHS Directive → Page G-38

*1 Single-Phase 220 VAC 50Hz type is not available for conduit box type.

*2 Conduit box type is not certified under the China Compulsory Certification System (CCC System).

TP: Contains a built-in thermal protector (automatic return type). If a motor overheats for any reason, the thermal protector is activated and the motor is stopped. When the motor temperature drops, the thermal protector closes and the motor restarts. Be sure to turn the motor power off before inspecting.

Product Line

Motor (RoHS)

Type	Model	
	Pinion Shaft Type	Round Shaft Type
Lead Wire	5IK60GE-AW2U	5IK60A-AW2U
	5IK60GE-CW2E	5IK60A-CW2E
Terminal Box	5IK60GE-SW2	5IK60A-SW2
	5IK60GE-AW2TU	5IK60A-AW2TU
Conduit Box	5IK60GE-CW2TE	5IK60A-CW2TE
	5IK60GE-SW2T	5IK60A-SW2T
	5IK60GE-FCH	5IK60A-FCH
	5IK60GE-ECH	5IK60A-ECH
	5IK60GE-SH	5IK60A-SH

The following items are included in each product.

Motor, Capacitor*, Capacitor Cap*, Operating Manual

* Only for single-phase motors (Excluding conduit box type)

Parallel Shaft Gearhead/Right-Angle Gearhead
(Sold separately) (RoHS)

Gearhead Type	Gearhead Model	Gear Ratio
Parallel Shaft	Long Life GE-S Gearhead	3, 3.6, 5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180
	Hollow Shaft	
	Solid Shaft	
Parallel Shaft	Long Life GE-S Gearhead	5GE10XS (Decimal Gearhead)

- Enter the gear ratio in the box (□) within the model name.

The following items are included in each product.

- Parallel Shaft Gearhead

Gearhead, Mounting Screws, Parallel Key, Operating Manual

- Hollow Shaft Gearhead

Gearhead, Mounting Screws, Parallel Key, Safety Cover (with screws), Gasket, Operating Manual

- Solid Shaft Gearhead

Gearhead, Mounting Screws, Parallel Key, Gasket, Operating Manual

Gearmotor – Torque Table

- Gearheads and decimal gearheads are sold separately.
 - Enter the code that represents the terminal box type "T" in the box (□) within the motor model name.
 - Enter the gear ratio in the box (□) within the gearhead model name.
 - A colored background (■) indicates gear shaft rotation in the same direction as the motor shaft, while the others rotate in the opposite direction.
 - The speed is calculated by dividing the motor's synchronous speed (50 Hz: 1500 r/min, 60 Hz: 1800 r/min) by the gear ratio.
The actual speed is 2~20% less than the displayed value, depending on the load.
 - To reduce the speed beyond the gear ratio in the table, attach a decimal gearhead (gear ratio 10:1) between the gearhead and the motor.
In that case, the permissible torque is 20 N·m (177 lb-in).

◆ 50 Hz

Unit = Upper values: N·m/Lower values: lb-in

Model	Speed r/min	500	416	300	250	200	166	120	100	83	60	50	41	30	25	20	16	15	12.5	10	8.3
	Gear Ratio	3	3.6	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150	180
5IK60GE-CW2■E 5IK60GE-ECH	5GE□SA	1.2	1.4	2.0	2.4	3.0	3.6	4.5	5.4	6.4	8.1	9.7	11.6	16.2	19.4	20	20	20	20	20	20
		10.6	12.3	17.7	21	26	31	39	47	56	71	85	102	143	171	177	177	177	177	177	177
5IK60GE-SW2■ 5IK60GE-SH	5GE□SA	1.1	1.3	1.8	2.2	2.7	3.3	4.1	4.9	5.9	7.4	8.9	10.7	14.9	17.8	19.9	20	20	20	20	20
		9.7	11.5	15.9	19.4	23	29	36	43	52	65	78	94	131	157	176	177	177	177	177	177

◇ 60 Hz

Unit = Upper values: N·m/lower values: lb-in

Model	Speed r/min	600	500	360	300	240	200	144	120	100	72	60	50	36	30	24	20	18	15	12	10
	Gear Ratio	3	3.6	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150	180
5IK60GE-AW2■U	5GE□SA	0.98	1.2	1.6	2.0	2.5	3.0	3.7	4.4	5.3	6.7	8.0	9.6	13.4	16.0	17.9	20	20	20	20	20
5IK60GE-CW2■E		8.6	10.6	14.1	17.7	22	26	32	38	46	59	70	84	118	141	158	177	177	177	177	177
5IK60GE-FCH																					
5IK60GE-ECH																					
5IK60GE-SW2■	5GE□SA	0.92	1.1	1.5	1.8	2.3	2.8	3.5	4.2	5.0	6.3	7.5	9.0	12.5	15.0	16.8	20	20	20	20	20
5IK60GE-SH		8.1	9.7	13.2	15.9	20	24	30	37	44	55	66	79	110	132	148	177	177	177	177	177

█ Gearmotor – Torque Table When Right-Angle Gearhead is Attached

→ Page A-248

■ Permissible Overhung Load and Permissible Thrust Load

Motor (Round shaft type) → Page A-16

Gearhead → Page A-16

Permissible Load Inertia J of Gearhead

→ Page A-17

Dimensions Unit = mm (in.)


- Mounting screws are included with gearheads. Dimensions for mounting screws → Page A-310

◆ Lead Wire Type ①

Mass: Motor 2.7 kg (5.9 lb.)
Gearhead 1.5 kg (3.3 lb.)

Motor Model	Gearhead Model	DXF
5IK60GE-AW2U		
5IK60GE-CW2E	5GE□SA	A455U
5IK60GE-SW2		


- Enter the gear ratio in the box (□) within the model name.



Detail Drawing of Protective Earth Terminal


◇ Terminal Box Type ②

Mass: Motor 2.8 kg (6.2 lb.)
Gearhead 1.5 kg (3.3 lb.)



Motor Model	Gearhead Model	DXF
5IK60GE-AW2TU		
5IK60GE-CW2TE	5GE□SA	
5IK60GE-SW2T		A457U


● Enter the gear ratio in the box (□) within the model name.



- Use cable with a diameter of Ø6 ~ Ø12 mm (Ø0.24 ~ Ø0.47 in.).
- Details of terminal box → Page A-314


◇ Key and Key Slot

(The key is included with the gearhead)



◇ Shaft Section of Round Shaft Type


The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.




◇Conduit Box Type ③

Motor Model	Gearhead Model	DXF
5IK60GE-FCH	5GE□SA	
5IK60GE-ECH		A904U

Mass: Motor 3.2 kg (7.0 lb.)
Gearhead 1.5 kg (3.3 lb.)




● Enter the gear ratio in the box (□) within the model name.



3 Motor Leads: UL Style 3266, AWG20
1 Ground Lead: UL Style 3266, AWG18
● Details of terminal box → Page A-314


◇Key and Key Slot

(The key is included with the gearhead)




Motor Model	Gearhead Model	DXF
5IK60GE-SH	5GE□SA	A905U

Mass: Motor 2.8 kg (6.2 lb.)
Gearhead 1.5kg (3.3 lb.)




● Enter the gear ratio in the box (□) within the model name.



3 Motor Leads: UL Style 3266, AWG20
1 Ground Lead: UL Style 3266, AWG18
● Details of terminal box → Page A-314

◇Key and Key Slot


(The key is included with the gearhead)



◇Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.

Motor Model	Mass	DXF
5IK60A-FCH	3.2 kg (7.0 lb.)	A813
5IK60A-ECH		




◇Decimal Gearhead

Can be connected to **GE** pinion shaft type.

5GE10XS


Mass: 0.6 kg (1.32 lb.)

DXF A029



◇Capacitor


(Included with single-phase motors)



◇Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.

Motor Model	Mass	DXF
5IK60A-SH	2.8 kg (6.2 lb.)	A814



◇Capacitor Dimensions Unit = mm (in.)

Model		Capacitor Model	A	B	C	Mass g (oz.)	Capacitor Cap
Upper Model Name: Pinion Shaft Type	Lower Model Name (: Round Shaft Type						
Lead Wire Type	Terminal Box Type						
5IK60GE-AW2U (5IK60A-AW2U)	5IK60GE-AW2TU (5IK60A-AW2TU)	CH180CFAUL2	58 (2.28)	29 (1.14)	41 (1.61)	92 (3.2)	Included
5IK60GE-CW2E (5IK60A-CW2E)	5IK60GE-CW2TE (5IK60A-CW2TE)	CH40BFAUL	58 (2.28)	23.5 (0.93)	37 (1.46)	73 (2.6)	

Connection Diagrams

- The direction of motor rotation is as viewed from the shaft end of the motor. CW represents the clockwise direction, while CCW represents the counterclockwise direction.
- Connection diagrams are also valid for the equivalent round shaft type.

Lead Wire Type		Terminal Box Type	
5IK60GE-AW2U 5IK60GE-CW2E	5IK60GE-SW2	5IK60GE-AW2TU 5IK60GE-CW2TE	5IK60GE-SW2T
Clockwise	Clockwise <p>Counterclockwise To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).</p>	Clockwise	Clockwise <p>Counterclockwise To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).</p>
Counterclockwise	Counterclockwise To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).	Counterclockwise	
Conduit Box Type			
5IK60GE-FCH 5IK60GE-ECH	5IK60GE-SH		
Clockwise <p>*NC: No connection</p>	Clockwise <p>Counterclockwise To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).</p>		
Counterclockwise <p>*NC: No connection</p>			

PE: Protective Earth

Note:

- Change the direction of single-phase motor rotation only after bringing the motor to a stop.
If an attempt is made to change the direction of rotation while the motor is rotating, motor may ignore reversing command or change its direction of rotation after some delay.
- How to connect a capacitor → Page A-313

Gearhead, Accessories and Peripheral Equipment

(Space-Saving)
Right-Angle Gearheads
→ Page A-239



Instantaneous Stop
Brake Pack
→ Page A-277



Speed Control
Speed Controller
→ Page B-156




Accessories
→ Page A-287



Induction Motors

90 W (1/8 HP)

Frame Size: □90 mm (□3.54 in.)

Terminal Box Type
(Gearhead sold separately)1 W, 3 W
(1/750 HP,
1/250 HP)6 W
(1/125 HP)15 W
(1/50 HP)25 W
(1/30 HP)40 W
(1/19 HP)60 W
(1/12 HP)90 W
(1/8 HP)200 W
(1/4 HP)2-Pole
40-50 W
(1/19-1/5 HP)

■ Specifications – Continuous Rating (RoHS)



Model Upper Model Name: Pinion Shaft Type Lower Model Name (): Round Shaft Type			Output Power W HP	Voltage VAC	Frequency Hz	Current A	Starting Torque mN·m oz-in	Rated Torque mN·m oz-in	Rated Speed r/min	Capacitor μF
Lead Wire Type Dimension ①	Terminal Box Type Dimension ②	Conduit Box Type Dimension ③								
(TP) 5IK90GE-AW2U (5IK90A-AW2U)	5IK90GE-AW2TU (5IK90A-AW2TU)	5IK90GE-FCH (5IK90A-FCH)	90 1/8	Single-Phase 110 Single-Phase 115	60 1.45 1.44	450 63	585 83	1500	20	
				50 60 50 60	0.74 0.82 0.76 0.81		730 103 605 85 730 103 605 85	1200 1450 1200 1450		
	(TP) 5IK90GE-CW2E (5IK90A-CW2E)	5IK90GE-CW2TE (5IK90A-CW2TE)	5IK90GE-ECH ^{*1} (5IK90A-ECH) ^{*1}	90 1/8	Single-Phase 220 Single-Phase 230		450 63			6.0
				50 60	0.74 0.82					
				50 60	0.76 0.81					
				50 60	0.64 0.59	850 700 700 700	120 99 99 99	680 570 570 570	1300 1550 1600 1600	
	(TP) 5IK90GE-SW2 (5IK90A-SW2)	5IK90GE-SW2T (5IK90A-SW2T)	5IK90GE-SH (5IK90A-SH)	90 1/8	Three-Phase 200 Three-Phase 220 Three-Phase 230	60 60 60	0.60 0.61	120 80 80	1600	
				60	0.61	700 700 700	99 99 99	570 570 570	1600	
				60	0.61	700 700 700	99 99 99	570 570 570	1600	

● The **U** and **E** at the end of the model name indicate that the unit includes a capacitor. These letters are not listed on the motor nameplate.
When the motor is approved under various safety standards, the model name on the nameplate is the approved model name. → Page G-11

- Details of safety standards → Page G-2
- Details of RoHS Directive → Page G-38

*1 Single-Phase 220 VAC 50Hz type is not available for conduit box type.

*2 Conduit box type is not certified under the China Compulsory Certification System (CCC System).

(TP): Contains a built-in thermal protector (automatic return type). If a motor overheats for any reason, the thermal protector is activated and the motor is stopped.
When the motor temperature drops, the thermal protector closes and the motor restarts. Be sure to turn the motor power off before inspecting.

■ Product Line

● Motor (RoHS)

Type	Model	
	Pinion Shaft Type	Round Shaft Type
Lead Wire	5IK90GE-AW2U	5IK90A-AW2U
	5IK90GE-CW2E	5IK90A-CW2E
Terminal Box	5IK90GE-SW2	5IK90A-SW2
	5IK90GE-AW2TU	5IK90A-AW2TU
Conduit Box	5IK90GE-CW2TE	5IK90A-CW2TE
	5IK90GE-SW2T	5IK90A-SW2T
	5IK90GE-FCH	5IK90A-FCH
	5IK90GE-ECH	5IK90A-ECH
	5IK90GE-SH	5IK90A-SH

The following items are included in each product.

Motor, Capacitor*, Capacitor Cap*, Operating Manual

* Only for single-phase motors (Excluding conduit box type)

● Parallel Shaft Gearhead/Right-Angle Gearhead
(Sold separately) (RoHS)

Gearhead Type	Gearhead Model	Gear Ratio
Parallel Shaft	Long Life GE-S Gearhead	3, 3.6, 5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180
Right-Angle Shaft	Hollow Shaft	
	Solid Shaft	
Parallel Shaft	Long Life GE-S Gearhead	5GE10XS (Decimal Gearhead)

● Enter the gear ratio in the box (□) within the model name.

The following items are included in each product.

● Parallel Shaft Gearhead

Gearhead, Mounting Screws, Parallel Key, Operating Manual

● Hollow Shaft Gearhead


Gearhead, Mounting Screws, Parallel Key, Safety Cover (with screws), Gasket, Operating Manual

● Solid Shaft Gearhead

Gearhead, Mounting Screws, Parallel Key, Gasket, Operating Manual


◇ Terminal Box Type ②

Mass: Motor 3.3 kg (7.3 lb.)
Gearhead 1.5 kg (3.3 lb.)



Motor Model	Gearhead Model	DXF
5IK90GE-AW2TU		
5IK90GE-CW2TE	5GE□SA	
5IK90GE-SW2T		A460U


● Enter the gear ratio in the box (□) within the model name.



- Use cable with a diameter of $\phi 6 \sim \phi 12$ mm ($\phi 0.24 \sim \phi 0.47$ in.).
- Details of terminal box → Page A-314


◇ Key and Key Slot

(The key is included with the gearhead)



◇ Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.




Motor Model	Mass	DXF
5IK90A-AW2U	3.2 kg (7.0 lb.)	A459
5IK90A-CW2E		
5IK90A-SW2		
5IK90A-AW2TU	3.3 kg (7.3 lb.)	A334
5IK90A-CW2TE		
5IK90A-SW2T		


◇ Conduit Box Type ③

Motor Model	Gearhead Model	DXF
5IK90GE-FCH	5GE□SA	
5IK90GE-ECH		A906U

Mass: Motor 3.7 kg (8.1 lb.)
Gearhead 1.5 kg (3.3 lb.)




● Enter the gear ratio in the box (□) within the model name.



3 Motor Leads: UL Style 3266, AWG20
1 Ground Lead: UL Style 3266, AWG18
● Details of terminal box → Page A-314



◇ Key and Key Slot

(The key is included with the gearhead)



Motor Model	Gearhead Model	DXF
5IK90GE-SH	5GE□SA	A907U


Mass: Motor 3.3 kg (7.3 lb.)
Gearhead 1.5 kg (3.3 lb.)



3 Motor Leads: UL Style 3266, AWG20
1 Ground Lead: UL Style 3266, AWG18
● Details of terminal box → Page A-314

◇ Key and Key Slot


(The key is included with the gearhead)



◇Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.

Motor Model	Mass	DXF
5IK90A-FCH	3.7 kg (8.1 lb.)	A815
5IK90A-ECH		




◇Decimal Gearhead

Can be connected to **GE** pinion shaft type.

5GE10XS



Mass: 0.6 kg (1.32 lb.)

DXF A029



◇Capacitor


(Included with single-phase motors)



◇Shaft Section of Round Shaft Type

The motor's dimensions (excluding the shaft section) are the same as those of the pinion shaft types.

Motor Model	Mass	DXF
5IK90A-SH	3.3 kg (7.3 lb.)	A816



◇Capacitor Dimensions Unit = mm (in.)

Model		Capacitor Model	A	B	C	Mass g (oz.)	Capacitor Cap
Upper Model Name: Pinion Shaft Type	Lower Model Name (): Round Shaft Type						
Lead Wire Type	Terminal Box Type						
5IK90GE-AW2U (5IK90A-AW2U)	5IK90GE-AW2TU (5IK90A-AW2TU)	CH200CFAUL2	58 (2.28)	29 (1.14)	41 (1.61)	91 (3.2)	Included
5IK90GE-CW2E (5IK90A-CW2E)	5IK90GE-CW2TE (5IK90A-CW2TE)	CH60BFAUL	58 (2.28)	29 (1.14)	41 (1.61)	92 (3.2)	

Connection Diagrams

- The direction of motor rotation is as viewed from the shaft end of the motor. CW represents the clockwise direction, while CCW represents the counterclockwise direction.
- Connection diagrams are also valid for the equivalent round shaft type.

Lead Wire Type		Terminal Box Type	
5IK90GE-AW2U 5IK90GE-CW2E	5IK90GE-SW2	5IK90GE-AW2TU 5IK90GE-CW2TE	5IK90GE-SW2T
Clockwise Counterclockwise 	Clockwise Counterclockwise <p>To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).</p>	Clockwise Counterclockwise 	Clockwise Counterclockwise <p>To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).</p>
Conduit Box Type		Conduit Box Type	
5IK90GE-FCH 5IK90GE-ECH	5IK90GE-SH	5IK90GE-FCH 5IK90GE-ECH	5IK90GE-SH
Clockwise <p>*NC: No connection</p> Counterclockwise <p>*NC: No connection</p>	Clockwise Counterclockwise <p>To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).</p>	Clockwise <p>*NC: No connection</p> Counterclockwise <p>*NC: No connection</p>	Clockwise Counterclockwise <p>To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).</p>

PE: Protective Earth

Note:

- Change the direction of single-phase motor rotation only after bringing the motor to a stop.
If an attempt is made to change the direction of rotation while the motor is rotating, motor may ignore reversing command or change its direction of rotation after some delay.
- How to connect a capacitor → Page A-313

Gearhead, Accessories and Peripheral Equipment

Space-Saving Right-Angle Gearheads
→Page A-239




Instantaneous Stop Brake Pack
→Page A-277



Speed Control Speed Controller
→Page B-156



Accessories
→Page A-287



High Power Induction Motors BH Series

200 W (1/4 HP)

Frame Size: □104 mm (□4.09 in.)

Cable Type
Right-Angle Hollow ShaftTerminal Box Type
Parallel Shaft1 W, 3 W
(1/750 HP,
1/250 HP)6 W
(1/125 HP)15 W
(1/50 HP)25 W
(1/30 HP)40 W
(1/19 HP)60 W
(1/12 HP)90 W
(1/8 HP)200 W
(1/4 HP)2-Pole
40-150 W
(1/19-1/5 HP)

Features

- High Power 200 W (1/4 HP)

Smallest frame size among 200 W (1/4 HP) motors

- Hypoid Gear-Employed Right-Angle Gearheads

Right-angle gearheads employ hypoid gears. Hollow shafts and solid shafts are available to enable space-saving.

- RoHS Compliant

The BH Series conforms to the RoHS Directive that prohibits the use of six chemical substances including lead and cadmium.

● Details of RoHS Directive → Page G-38

- "Combination Type" for Easy Installation

The combination type comes with the motor and gearhead pre-assembled. This enables easy installation in equipment.

Combination Type:

The combination type comes with the motor and its dedicated gearhead pre-assembled, which simplifies installation in equipment. Motors and gearheads are also available separately to facilitate changes or repairs.

Specifications – Continuous Rating (RoHS)



Model Combination Type () : Round Shaft Type		Output Power W HP	Voltage VAC	Frequency Hz	Current A	Starting Torque N·m oz-in	Rated Torque N·m oz-in	Rated Speed r/min	Capacitor μF	
Cable Type	Terminal Box Type									
(TP) BHI62F-□RH BHI62F-□RA BHI62F-□ (BHI62F-A)	BHI62FT-□RH BHI62FT-□RA BHI62FT-□ (BHI62FT-A)	200 1/4	Single-Phase 110	60	3	0.88 124	1.27 180	1500	40	
						0.98 139				
		200 1/4	Single-Phase 220	60	1.5	0.98 139	1.27 180	1500		
				50			1.52 210	1250		
				60			1.27 180	1500		
(TP) BHI62E-□RH BHI62E-□RA BHI62E-□ (BHI62E-A)	BHI62ET-□RH BHI62ET-□RA BHI62ET-□ (BHI62ET-A)	200 1/4	Single-Phase 230	60	1.5	0.98 139	1.27 180	1500	10	
				50			1.52 210	1250		
				60			1.27 180	1500		
				50	1.1	1.49 210	1.49 210	1250		
				60		1.25 177	1.25 177	1500		
		200 1/4	Three-Phase 200	60	0.95	1.23 174	1.23 174	1550		
				60		1.18 167	1.18 167	1600		
(TP) —	BHI62ST-□RH BHI62ST-□RA BHI62ST-□ (BHI62ST-A)	200 1/4	Three-Phase 220	60	0.95	1.23 174	1.23 174	1550	—	
				60						
				60						
			Three-Phase 230	60		1.18 167	1.18 167	1600		
				60						
				60						
				60						

● Enter the gear ratio in the box (□) within the model name. The values for each specification applies to the motor only.

● Details of safety standards → Page G-2

● List of safety standard approved products (Model, Standards, Standards File No., Certification Body) → Page G-11

(TP): Contains a built-in thermal protector (automatic return type). If a motor overheats for any reason, the thermal protector is activated and the motor is stopped. When the motor temperature drops, the thermal protector closes and the motor restarts. Be sure to turn the motor power off before inspecting.

Product Line

- Combination Type (RoHS)

◇ Right-Angle Shaft

Type	Voltage	Model	Gear Ratio
Hollow Shaft Cable	Single-Phase 110/115 VAC	BHI62F-□RH	5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180
	Single-Phase 220/230 VAC	BHI62E-□RH	
Hollow Shaft Terminal Box	Single-Phase 110/115 VAC	BHI62FT-□RH	5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180
	Single-Phase 220/230 VAC	BHI62ET-□RH	
Solid Shaft Cable	Single-Phase 110/115 VAC	BHI62F-□RA	5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180
	Single-Phase 220/230 VAC	BHI62E-□RA	
Solid Shaft Terminal Box	Single-Phase 110/115 VAC	BHI62FT-□RA	5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180
	Single-Phase 220/230 VAC	BHI62ET-□RA	
	Three-Phase 200/220/230 VAC	BHI62ST-□RH	

● Enter the gear ratio in the box (□) within the model name.

— The following items are included in each product.

Motor, Gearhead, Capacitor*, Capacitor Cap*, Parallel Key, Operating Manual

* Only for single-phase motors

◇ Parallel Shaft

Type	Voltage	Model	Gear Ratio
Parallel Shaft Cable	Single-Phase 110/115 VAC	BHI62F-□	3, 3.6, 5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180
	Single-Phase 220/230 VAC	BHI62E-□	
Parallel Shaft Terminal Box	Single-Phase 110/115 VAC	BHI62FT-□	3, 3.6, 5, 6, 7.5, 9, 12.5, 15, 18, 25, 30, 36, 50, 60, 75, 90, 100, 120, 150, 180
	Single-Phase 220/230 VAC	BHI62ET-□	
	Three-Phase 200/220/230 VAC	BHI62ST-□	

● Enter the gear ratio in the box (□) within the model name.

The following items are included in each product.

Motor, Gearhead, Capacitor®, Capacitor Cap®, Mounting Screws, Parallel Key, Operating Manual
* Only for single-phase motors

● Round Shaft Type (RoHS)

Type	Voltage	Model
Cable	Single-Phase 110/115 VAC	BHI62F-A
	Single-Phase 220/230 VAC	BHI62E-A
Terminal Box	Single-Phase 110/115 VAC	BHI62FT-A
	Single-Phase 220/230 VAC	BHI62ET-A
	Three-Phase 200/220/230 VAC	BHI62ST-A

The following items are included in each product.

Motor, Capacitor®, Capacitor Cap®, Operating Manual

* Only for single-phase motors

■ Gearmotor – Torque Table for Combination Type

● Enter the code that represents the terminal box type "T" in the box (□) within the model name.

● Enter the gear ratio in the box (□) within the model name.

● A colored background (□) indicates gear shaft rotation in the same direction as the motor shaft, while the others rotate in the opposite direction.

● The speed is calculated by dividing the motor's synchronous speed (50 Hz: 1500 r/min, 60 Hz: 1800 r/min) by the gear ratio.

The actual speed is 2~20% less than the displayed value, depending on the load.

● Decimal gearheads are not available for the **BH** series.

● Right-Angle Shaft 50 Hz

Model	Speed r/min	300	250	200	167	120	100	83	60	50	42	30	25	20	17	15	12.5	10	8.3
	Gear Ratio	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150	180
BHI62E-□-□RH, BHI62E-□-□RA		5.5	6.7	8.3	10.0	13.9	16.6	20.0	27.7	33.3	36.0	40.0	43.0	47.0	51.5	54.5	60	60	60
		48	59	73	88	123	146	177	240	290	310	350	380	410	450	480	530	530	530
BHI62ST-□-□RH, BHI62ST-□-□RA		5.4	6.5	8.2	9.8	13.6	16.3	19.6	27.2	32.6	36.0	40.0	43.0	47.0	51.5	54.5	60	60	60
		47	57	72	86	120	144	173	240	280	310	350	380	410	450	480	530	530	530

● Right-Angle Shaft 60 Hz

Model	Speed r/min	360	300	240	200	144	120	100	72	60	50	36	30	24	20	18	15	12	10
	Gear Ratio	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150	180
BHI62F-□-□RH, BHI62F-□-□RA		4.6	5.6	7.0	8.3	11.6	13.9	16.7	23.2	27.8	33.4	40.0	43.0	47.0	51.5	54.5	60	60	60
		40	49	61	73	102	123	147	200	240	290	350	410	450	480	530	530	530	530
BHI62ST-□-□RH, BHI62ST-□-□RA (200 VAC)		4.6	5.5	6.8	8.2	11.4	13.7	16.4	22.8	27.4	32.9	40.0	43.0	47.0	51.5	54.5	60	60	60
		40	48	60	72	100	121	145	200	240	290	350	380	410	450	480	530	530	530
BHI62ST-□-□RH, BHI62ST-□-□RA (220 VAC)		4.5	5.4	6.7	8.1	11.2	13.5	16.2	22.4	26.9	32.3	40.0	43.0	47.0	51.5	54.5	60	60	60
		39	47	59	71	99	119	143	198	230	280	350	380	410	450	480	530	530	530
BHI62ST-□-□RH, BHI62ST-□-□RA (230 VAC)		4.3	5.2	6.5	7.8	10.8	12.9	15.5	21.5	25.8	31.0	40.0	43.0	47.0	51.5	54.5	60	60	60
		38	46	57	69	95	114	137	190	220	270	350	380	410	450	480	530	530	530

● Parallel Shaft 50 Hz

Model	Speed r/min	500	417	300	250	200	167	120	100	83	60	50	42	30	25	20	17	15	12.5	10	8.3
	Gear Ratio	3	3.6	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150	180
BHI62E-□-□		4.1	4.9	6.8	8.2	10.3	12.3	16.3	19.6	23.5	32.7	39.2	40	40	40	40	40	40	40	40	40
		36	43	60	72	91	108	144	173	200	280	340	350	350	350	350	350	350	350	350	350
BHI62ST-□		4.0	4.8	6.7	8.0	10.1	12.1	16.0	19.2	23.1	32.0	38.4	40	40	40	40	40	40	40	40	40
		35	42	59	70	89	107	141	169	200	280	330	350	350	350	350	350	350	350	350	350

● Parallel Shaft 60 Hz

Model	Speed r/min	600	500	360	300	240	200	144	120	100	72	60	50	36	30	24	20	18	15	12	10
	Gear Ratio	3	3.6	5	6	7.5	9	12.5	15	18	25	30	36	50	60	75	90	100	120	150	180
BHI62F-□-□, BHI62E-□-□		3.4	4.1	5.7	6.9	8.6	10.3	13.7	16.4	19.7	27.3	32.8	39.3	40	40	40	40	40	40	40	40
		30	36	50	61	76	91	121	145	174	240	290	340	350	350	350	350	350	350	350	350
BHI62ST-□ (200 VAC)		3.4	4.1	5.6	6.8	8.4	10.1	13.4	16.1	19.4	26.9	32.3	38.7	40	40	40	40	40	40	40	40
		30	36	49	60	74	89	118	142	171	230	280	340	350	350	350	350	350	350	350	350
BHI62ST-□ (220 VAC)		3.3	4.0	5.5	6.6	8.3	10.0	13.2	15.9	19.0	26.4	31.7	38.1	40	40	40	40	40	40	40	40
		29	35	48	58	73	88	116	140	168	230	280	330	350	350	350	350	350	350	350	350
BHI62ST-□ (230 VAC)		3.2	3.8	5.3	6.4	8.0	9.6	12.7	15.2	18.3	25.4	30.4	36.5	40	40	40	40	40	40	40	40
		28	33	46	56	70	84	112	134	161	220	260	320	350	350	350	350	350	350	350	350

■ Permissible Overhung Load and Permissible Thrust Load

Combination Type → Page A-16

Round Shaft Type → Page A-16

■ Permissible Load Inertia J of Gearhead

→ Page A-17

■ Dimensions Unit = mm (in.)

- Mounting screws are included with the combination type, parallel shaft. Dimensions for mounting screws → Page A-310

◊ Combination Type: Right-Angle, Hollow Shaft (Cable Type)

BHI62F-□RH, BHI62E-□RH

Mass: 10.0 kg (22 lb.)





Motor: BHI62F-G2, BHI62E-G2

Gearhead: BH6G2-□RH

DXF A299

◊ Key

(The key is included with the gearhead)



- Enter the gear ratio in the box (□) within the model name.

◇ Combination Type: Right-Angle, Solid Shaft (Cable Type)


BHI62F-□RA, BHI62E-□RA

Mass: 10.0 kg (22 lb.)


Motor: BHI62F-G2, BHI62E-G2

Gearhead: BHG62-□RA

DXF A300



◇ Key and Key Slot



● At the time of shipment, a key is inserted on the gearhead's shaft.

● Enter the gear ratio in the box (□) within the model name.

◇ Combination Type: Right-Angle, Hollow Shaft (Terminal Box Type)



BHI62FT-□RH, BHI62ET-□RH, BHI62ST-□RH

Mass: 10.0 kg (22 lb.)

Motor: BHI62FT-G2, BHI62ET-G2, BHI62ST-G2



Gearhead: BHG6G2-□RH

DXF A301

1 W, 3 W
(1/750 HP,
1/250 HP)6 W
(1/125 HP)15 W
(1/50 HP)25 W
(1/30 HP)40 W
(1/19 HP)60 W
(1/12 HP)90 W
(1/8 HP)200 W
(1/4 HP)2-Pole
40-150 W
(1/19-1/5 HP)

◇ Key

(The key is included with the gearhead)

● Use cable with a diameter of $\phi 6 \sim \phi 12$ mm ($\phi 0.24 \sim \phi 0.47$ in.).

● Details of terminal box → Page A-314

● Enter the gear ratio in the box (□) within the model name.

◇ Combination Type: Right-Angle, Solid Shaft (Terminal Box Type)


BHI62FT-□RA, BHI62ET-□RA, BHI62ST-□RA

Mass: 10.0 kg (22 lb.)

Motor: BHI62FT-G2, BHI62ET-G2, BHI62ST-G2


Gearhead: BHG62-□RA

DXF A302

● Use cable with a diameter of $\phi 6 \sim \phi 12$ mm ($\phi 0.24 \sim \phi 0.47$ in.).

● Details of terminal box → Page A-314

◇ Key and Key Slot



● At the time of shipment, a key is inserted on the gearhead's shaft.

● Enter the gear ratio in the box (□) within the model name.

◇ Combination Type: Parallel Shaft (Terminal Box Type)


BHI62F-□, BHI62E-□

Mass: 8.0 kg (18 lb.)

Motor: BHI62F-G2, BHI62E-G2

Gearhead: BH6G2-□

DXF A303


**BHI62FT-□, BHI62ET-□, BHI62ST-□**

Mass: 8.0 kg (18 lb.)

Motor: BHI62FT-G2, BHI62ET-G2, BHI62ST-G2

Gearhead: BH6G2-□


DXF A304



● Use cable with a diameter of φ6~φ12 mm (φ0.24~φ0.47 in.).

● Details of terminal box → Page A-314

◇ Key and Key Slot



● At the time of shipment, a key is inserted on the gearhead's shaft.

● Enter the gear ratio in the box (□) within the model name.

Standard AC Motors


Introduction	Induction Motors	Reversible Motors	Electro-magnetic Brake Motors	V Series	Clutch & Brake Motors	Synchronous Motors	Low-Speed Synchronous Motors	Watertight, Dust-resistant Motors	Torque Motors	Right-Angle Gearheads	Linear Heads	Brake Pack	Accessories	Installation
--------------	------------------	-------------------	-------------------------------	----------	-----------------------	--------------------	------------------------------	-----------------------------------	---------------	-----------------------	--------------	------------	-------------	--------------

◇Round Shaft Type (Cable Type)

BHI62F-A, BHI62E-A

Mass: 5.0 kg (11 lb.)

DXF A307




◇Round Shaft Type (Terminal Box Type)

BHI62FT-A, BHI62ET-A, BHI62ST-A

Mass: 5.0 kg (11 lb.)

DXF A308




● Use cable with a diameter of Ø6~Ø12 mm (Ø0.24~Ø0.47 in.).

● Details of terminal box → Page A-314

1 W, 3 W
(1/750 HP)
(1/250 HP)6 W
(1/125 HP)15 W
(1/50 HP)25 W
(1/30 HP)40 W
(1/19 HP)60 W
(1/12 HP)90 W
(1/8 HP)200 W
(1/4 HP)2-Pole
40-50 W
(1/19-1/5 HP)

◇ Capacitor (Included with single-phase motors)



◇ Capacitor Dimensions Unit = mm (in.)


Model		Capacitor Model	A	B	C	Mass g (oz.)	Capacitor Cap
Cable Type	Terminal Box Type						
BHI62F-□RH	BHI62FT-□RH	CH400CFAUL2	58 (2.28)	41 (1.61)	58 (2.28)	175 (6.2)	Included
BHI62F-□RA	BHI62FT-□RA						
BHI62F-□	BHI62FT-□						
BHI62F-A	BHI62FT-A						
BHI62E-□RH	BHI62ET-□RH	CH100BFAUL	58 (2.28)	35 (1.38)	50 (1.97)	132 (4.7)	
BHI62E-□RA	BHI62ET-□RA						
BHI62E-□	BHI62ET-□						
BHI62E-A	BHI62ET-A						

● Enter the gear ratio in the box (□) within the model name.

■ Mounting Method for Right-Angle, Hollow Shaft Types

These figures below show how to mount loads depending on the shape of the shaft. The tolerance of the inner diameter for the hollow shaft is finished as shown in the table on the right, and "key slot" processing is given to mount the load shaft. Use the key provided with the product by fastening it to the shaft. Apply a coating of molybdenum disulfide or similar grease to the surface of the load shaft and to the inner diameter of the load shaft to prevent sticking. Recommended load shaft diameter and inner diameter of hollow shaft are shown in the table on the right.

● Stepped Load Shaft



● After securing a load, attach the safety cover included.

Notes:

- Be careful not to apply a shock to the hollow shaft when mounting a load shaft. It may damage the bearing inside the gearhead.
- Bolts or other fasteners used to install the load shaft are not included. These parts must be purchased separately.


● Inner Diameter of Hollow Shaft and Recommended Load Shaft Diameter

Unit = mm (in.)

Model	BH6G2-□RH
Inner Diameter of Hollow Shaft H8	$\phi 25^{+0.033}_0$ ($\phi 0.9843^{+0.0013}_0$)
Recommended Load Shaft Diameter h7	$\phi 25^0_{-0.021}$ ($\phi 0.9843^0_{-0.0008}$)











● Enter the gear ratio in the box (□) within the model name.

● Straight Load Shaft



Connection Diagrams

- The direction of motor rotation is as viewed from the shaft end of the motor. CW represents the clockwise direction, while CCW represents the counterclockwise direction.
- Enter the voltage (F, E) in the box (□) within the model name.

Motor Type	Single-Phase Induction Motor		Three-Phase Induction Motor
	Cable Type	Terminal Box Type*	Terminal Box Type*
Combination Type: Parallel Shaft	BHI62□-3~9 BHI62□-50~180	BHI62□T-3~9 BHI62□T-50~180	BHI62ST-3~9 BHI62ST-50~180
	Clockwise 	Clockwise 	Clockwise 
	Counterclockwise 	Counterclockwise 	Counterclockwise To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).
	BHI62□-12.5~36	BHI62□T-12.5~36	BHI62ST-12.5~36
	Clockwise 	Clockwise 	Clockwise 
	Counterclockwise 	Counterclockwise 	Counterclockwise To change the rotation direction, change any two connections between L1(S), L2(R) and L3(T).

PE: Protective Earth

*Connecting to the terminal








Applicable lead wires: AWG24~12

Strip length: 8 mm (0.315 in.)

Note:

- Change the direction of single-phase motor rotation only after bringing the motor to a stop. If an attempt is made to change the direction of rotation while the motor is rotating, motor may ignore reversing command or change its direction of rotation after some delay.

- How to connect a capacitor → Page A-313

	1 W, 3 W (1/750 HP, 1/250 HP)	BHI62□-5RH~180RH BHI62□-5RA~180RA
	6 W (1/125 HP)	Clockwise CW 
	15 W (1/50 HP)	Counter-clockwise CCW 
	25 W (1/30 HP)	Clockwise CW 
	40 W (1/19 HP)	BHI62□-A
	60 W (1/12 HP)	Clockwise CW 
	90 W (1/8 HP)	Counter-clockwise CCW 
2-Pole 40-150 W (1/19-1/5 HP)	200 W (1/4 HP)	BHI62□T-A
		Clockwise CW 
		Counter-clockwise CCW 

PE: Protective Earth

* Connecting to the terminal

Applicable lead wires: AWG24~12

Strip length: 8 mm (0.315 in.)

Note:

- Change the direction of single-phase motor rotation only after bringing the motor to a stop. If an attempt is made to change the direction of rotation while the motor is rotating, motor may ignore reversing command or change its direction of rotation after some delay.

- How to connect a capacitor → Page A-313

List of Motor and Gearhead Combinations

Motor and gearhead combinations are shown below.

Combination Type: Right Angle Shaft

Model	Motor Model	Gearhead Model
BHI62F-□RH	BHI62F-G2	BH6G2-□RH
BHI62F-□RA		BH6G2-□RA
BHI62FT-□RH	BHI62FT-G2	BH6G2-□RH
BHI62FT-□RA		BH6G2-□RA
BHI62E-□RH	BHI62E-G2	BH6G2-□RH
BHI62E-□RA		BH6G2-□RA
BHI62ET-□RH	BHI62ET-G2	BH6G2-□RH
BHI62ET-□RA		BH6G2-□RA
BHI62ST-□RH	BHI62ST-G2	BH6G2-□RH
BHI62ST-□RA		BH6G2-□RA

● Enter the gear ratio in the box (□) within the model name.

Combination Type: Parallel Shaft

Model	Motor Model	Gearhead Model
BHI62F-□	BHI62F-G2	
BHI62FT-□	BHI62FT-G2	
BHI62E-□	BHI62E-G2	BH6G2-□
BHI62ET-□	BHI62ET-G2	
BHI62ST-□	BHI62ST-G2	

● Enter the gear ratio in the box (□) within the model name.

Accessories and Peripheral Equipment

Speed Control
Speed Controller
→ Page B-156




Accessories
→ Page A-287



Induction Motors 2-Pole, High-Speed Type

40 W (1/19 HP), 60 W (1/12 HP), 90 W (1/8 HP), 150 W (1/5 HP)

Frame Size: □80 mm (□3.15 in.), □90 mm (□3.54 in.)



■ Specifications – Continuous Rating (RoHS)

Model	Output Power	Voltage	Frequency	Current	Starting Torque	Rated Torque	Rated Speed	Capacitor
Round Shaft Type	W HP	VAC	Hz	A	mN·m oz-in	mN·m oz-in	r/min	μF
(TP) 4IK40A-BW2U	40 1/19	Single-Phase 110	60	0.68	90	12.7	2900	7.5
		Single-Phase 115		0.66				
	36 1/20	Single-Phase 220	50	0.30			145 20	1.8
		Single-Phase 220		0.31			120 17.0	
(TP) 4IK40A-DW3E	40 1/19	Single-Phase 230	50	0.33			160 22	
		Single-Phase 230		0.32			135 19.1	
	60 1/12	Single-Phase 110	60	0.98	160	22	3000	10
		Single-Phase 115		0.97				
(TP) 4IK60A-DW3E	55 1/14	Single-Phase 220	50	0.44			210 29	2.5
		Single-Phase 220		0.51			180 25	
	60 1/12	Single-Phase 230	50	0.47			230 32	
		Single-Phase 230		0.52			190 26	
(TP) 5IK60A-BW2U	60 1/12	Single-Phase 110	60	0.94	140	19.8	3200	14
		Single-Phase 115		0.93				
	60 1/12	Single-Phase 220	50	0.46	120	17.0	220 31	3.0
		Single-Phase 220		0.46			185 26	
		Single-Phase 230	50	0.45			220 31	
		Single-Phase 230		0.45			185 26	
(TP) 5IK60A-DW3E	60 1/12	Three-Phase 200	50	0.47	270	38	220 31	—
		Three-Phase 220	60	0.40	230	32	185 26	
		Three-Phase 230	60	0.42	230	32	185 26	
		Three-Phase 230	60	0.44	230	32	185 26	
(TP) 5IK90A-BW2U	90 1/8	Single-Phase 110	60	1.61	240	34	3200	25
		Single-Phase 115		1.57				
		Single-Phase 220	50	0.70			330 46	6.0
		Single-Phase 220		0.84			280 39	
(TP) 5IK90A-DW3E	90 1/8	Single-Phase 230	50	0.69			330 46	
		Single-Phase 230		0.84			280 39	
		Three-Phase 200	50	0.63	500	71	340 48	—
		Three-Phase 200	60	0.55	400	56	285 40	
(TP) 5IK90A-TW2	90 1/8	Three-Phase 220	60	0.57	400	56	285 40	
		Three-Phase 230	60	0.59	400	56	285 40	
		Single-Phase 110	60	2.12	380	53	3200	30
		Single-Phase 115		2.09				
(TP) 5IK150A-DW3E	140 1/5	Single-Phase 220	50	0.98			510 72	8.0
		Single-Phase 220	60	1.07			420 59	
	150 1/5	Single-Phase 230	50	1.04			560 79	
		Single-Phase 230	60	1.13			460 65	
(TP) 5IK150A-TW2	150 1/5	Three-Phase 200	50	1.11	680	96	550 78	—
		Three-Phase 200	60	0.93	570	80	460 65	
		Three-Phase 220	60	0.97	570	80	460 65	
		Three-Phase 230	60	1.01	570	80	460 65	

● The **U** and **E** at the end of the model name indicate that the unit includes a capacitor. These letters are not listed on the motor nameplate.

When the motor is approved under various safety standards, the model name on the nameplate is the approved model name. → Page G-11

● Details of safety standards → Page G-2

● Details of RoHS Directive → Page G-38

(TP): Contains a built-in thermal protector (automatic return type). If a motor overheats for any reason, the thermal protector is activated and the motor is stopped.

When the motor temperature drops, the thermal protector closes and the motor restarts. Be sure to turn the motor power off before inspecting.

Product Line

● Motor RoHS

Output Power	Voltage	Model
40 W (1/19 HP)	Single-Phase 110/115 VAC	4IK40A-BW2U
	Single-Phase 220/230 VAC	4IK40A-DW3E
60 W (1/12 HP)	Single-Phase 110/115 VAC	4IK60A-BW2U
	Single-Phase 220/230 VAC	4IK60A-DW3E
	Single-Phase 110/115 VAC	5IK60A-BW2U
	Single-Phase 220/230 VAC	5IK60A-DW3E
90 W (1/8 HP)	Three-Phase 200/220/230 VAC	5IK60A-TW2
	Single-Phase 110/115 VAC	5IK90A-BW2U
	Single-Phase 220/230 VAC	5IK90A-DW3E
	Three-Phase 200/220/230 VAC	5IK90A-TW2
150 W (1/5 HP)	Single-Phase 110/115 VAC	5IK150A-BW2U
	Single-Phase 220/230 VAC	5IK150A-DW3E
	Three-Phase 200/220/230 VAC	5IK150A-TW2
	Three-Phase 200/220/230 VAC	5IK150A-TW2T

—The following items are included in each product.—

the following items are included in each product:

* Only for single-phase motors


Dimensions Unit = mm (in.)

● 40 W (1/19 HP)


4JK40A-BW2U **4JK40A-DW3E**

Mass: 1.5 kg (3.3 lb.)

DXF A450



Motor Leads 300 mm
UL Style 3271, AWG2




Detail Drawing of Protective Earth Terminal

● 60 W (1/12 HP)


4IK60A-BW2U, 4IK60A-DW3E

Mass: 1.8 kg (4.0 lb.)

Mass: 11.6 kg



Motor Leads 300 mm (12 in.) Length
UL Style 3271, AWG20






Detail Drawing of Protective Earth Terminal

5IK60A-BW2U, 5IK60A-DW3E, 5IK60A-TW2




Mass: 2.5 kg (5.5 lb.)

DXF A453

**90 W (1/8 HP)****5IK90A-BW2U, 5IK90A-DW3E, 5IK90A-TW2**




Mass: 2.7 kg (5.9 lb.)

DXF A456

**150 W (1/5 HP)****5IK150A-BW2U, 5IK150A-DW3E, 5IK150A-TW2**

Mass: 3.2 kg (7.0 lb.)

DXF A459




Detail Drawing of Protective Earth Terminal

5IK150A-TW2T

Mass: 3.3 kg (7.3 lb.)


DXF A334



● Use cable with a diameter of $\phi 6 \sim \phi 12$ mm ($\phi 0.24 \sim \phi 0.47$ in.).

● Details of terminal box → Page A-314

● Capacitor (Included with single-phase motors)







◇ Capacitor Dimensions Unit = mm (in.)

Model	Capacitor Model	A	B	C	Mass g (oz.)	Dimension No.	Capacitor Cap
4IK40A-BW2U	CH75CFAUL2	48 (1.89)	21 (0.83)	31 (1.22)	41 (1.45)	①	
4IK40A-DW3E	CH18BFAUL	38 (1.50)	21 (0.83)	31 (1.22)	37 (1.31)	①	
4IK60A-BW2U	CH100CFAUL2	58 (2.28)	21 (0.83)	31 (1.22)	49 (1.73)	①	
4IK60A-DW3E	CH25BFAUL	48 (1.89)	21 (0.83)	31 (1.22)	42 (1.48)	①	
5IK60A-BW2U	CH140CFAUL2	58 (2.28)	22 (0.87)	35 (1.38)	61 (2.2)	①	
5IK60A-DW3E	CH30BFAUL	58 (2.28)	21 (0.83)	31 (1.22)	50 (1.77)	①	
5IK90A-BW2U	CH250CFAUL2	58 (2.28)	35 (1.38)	50 (1.97)	140 (4.9)	②	
5IK90A-DW3E	CH60BFAUL	58 (2.28)	29 (1.14)	41 (1.61)	92 (3.2)	②	
5IK150A-BW2U	CH300CFAUL2	58 (2.28)	35 (1.38)	50 (1.97)	140 (4.9)	②	
5IK150A-DW3E	CH80BFAUL	58 (2.28)	35 (1.38)	50 (1.97)	136 (4.6)	②	

Included

■ Connection Diagrams

- The direction of motor rotation is as viewed from the shaft end of the motor. CW represents the clockwise direction, while CCW represents the counterclockwise direction.

		Three-Phase 200/220/230 VAC	
		Lead Wire Type	Terminal Box Type
Single-Phase 110/115 VAC Single-Phase 220/230 VAC		5IK60A-TW2 5IK90A-TW2 5IK150A-TW2	
1 W, 3 W (1/750 HP)			5IK150A-TW2T
6 W (1/125 HP)	Clockwise		
15 W (1/50 HP)	Counterclockwise		
25 W (1/30 HP)	Clockwise		Counterclockwise To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).
40 W (1/19 HP)	CCW		Counterclockwise To change the rotation direction, change any two connections between L1(R), L2(S) and L3(T).

PE: Protective Earth

Note:

- Change the direction of single-phase motor rotation only after bringing the motor to a stop.
If an attempt is made to change the direction of rotation while the motor is rotating, motor may ignore reversing command or change its direction of rotation after some delay.
- How to connect a capacitor → Page A-313